Submit 3 Copies To Appropriate District	State of New Mo	exico	Form C-103
Office District I	Energy, Minerals and Nati	ural Resources	May 27, 2004
1625 N. French Dr., Hobbs, NM 88240	23,		WELL API NO.
District II	OIL CONSERVATION	IDIVISION	30-025-37453
1301 W. Grand Ave., Artesia, NM 88210 District III			5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fra		STATE FEE
District IV	Santa Fe, NM 8	7505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505			
	CES AND REPORTS ON WELLS	3	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR TO DEEPEN OR PL	UG BACK TO A	
DIFFERENT RESERVOIR. USE "APPLIC	CATION FOR PERMIT" (FORM C-101) F	OR SUCH .	Eagle 2 State
PROPOSALS.) 1. Type of Well: Oil Well	Gas Wall Other		8. Well Number
1. Type of well. Off well	Gas well 🖂 Other		1
2. Name of Operator			9. OGRID Number
Samson Resources			20165
3. Address of Operator			10. Pool name or Wildcat
1010 N Loraine Street, Suite 1010;	Midland, TX 79701		Lea;Penn
4. Well Location			
Unit Letter O	: 660 feet from the South	line and1600	feet from the <u>East</u> line
Section 2	Township 20S	Range 34E	NMPM Lea County
2	11. Elevation (Show whether DR		
	3667 GR	., 1112, 111, 111, 111,	
Pit or Below-grade Tank Application 🔲 o	r Closure 🗌		
Pit typeDepth to Groundwate	erDistance from neare	est fresh water well	Distance from nearest surface water
Pit Liner Thickness:	mil Below-Grade Tank: Volume	bbls; Const	ruction Material
	Ammanuista Day ta Indiasta N	Intura of Matina 1	Donart on Other Data
12. Check A	Appropriate Box to Indicate N	valure of Notice, i	Report of Other Data
		01100	SECUENT DEDOCT OF
NOTICE OF IN	ITENTION TO:	∃ SUBS	SEQUENT REPORT OF:
NOTICE OF IN			SEQUENT REPORT OF: C
PERFORM REMEDIAL WORK	PLUG AND ABANDON 🗌	REMEDIAL WORK	
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	PLUG AND ABANDON CHANGE PLANS	REMEDIAL WORK	(□ ALTERING CASING □ LING OPNS.□ P AND A □
PERFORM REMEDIAL WORK	PLUG AND ABANDON 🗌	REMEDIAL WORK	(□ ALTERING CASING □ LING OPNS.□ P AND A □
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and	ALTERING CASING LLING OPNS. P AND A STORM TO THE STORM TO
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comp	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Deleted operations. (Clearly state all	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and	ALTERING CASING LLING OPNS. P AND A STORM TO THE STORM TO
PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING OTHER: 13. Describe proposed or compostarting any proposed we	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Deleted operations. (Clearly state all	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and	ALTERING CASING LLING OPNS. P AND A STORM TO THE STORM TO
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comp	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Deleted operations. (Clearly state all	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and	ALTERING CASING LLING OPNS. P AND A STORM STORM STORM P AND A STORM STOR
PERFORM REMEDIAL WORK TEMPORARILY ABANDON OF THE	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Deleted operations. (Clearly state all	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and	ALTERING CASING LING OPNS. P AND A STORM S
PERFORM REMEDIAL WORK TEMPORARILY ABANDON TEMPORARILY ABANDON TO THER: 13. Describe proposed or compof starting any proposed we or recompletion. 10/24/2007 – 11/25/2007	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL COMPL COMPL COMPL COMPL COMPL COMPL COMPL COMPL COMPLETE COMPL COMPLETE COMPLICATION COMPLETE COMPLICATION COMPLETE COMPLICATION COMPLETE COMPLETE COMPLETE COMPLETE COMPLETE COMPLICATION COMPL	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and	ALTERING CASING LING OPNS. P AND A STORM S
PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING THER: 13. Describe proposed or compof starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL COMPLETE COMPL COMPLETE COMPLICATION COMPLETE COMPLITATION COMPLETE COMPLICATION COMPLETE COMPLETE COMPLETE COMPLETE COMPLETE COMPLETE COMPLETE COMPLETE COMPLICATION COMPLETE COMPLICATION COMPLICATION COMPLETE COMPLICATION COMPLICATION COMPLICATION COMPLICATION CO	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LLING OPNS. P AND A DOB DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON TEMPORARILY ABANDON TO THE TEMPOR	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Completed operations. (Clearly state all ork). SEE RULE 1103. For Multiple Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LLING OPNS. P AND A DOB DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON TEMPORARILY ABANDON TO PULL OR ALTER CASING TO THER: 13. Describe proposed or compost of starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 130	PLUG AND ABANDON CHANGE PLANS SUBJECT OF THE PLANS SHAPE OF THE PLANS STATE OF THE PLANS SEE RULE 1103. For Multiput Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 1000'. ND BOP. NU tree. Swab test.	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LLING OPNS. P AND A DOB DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING THER: 13. Describe proposed or compof starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 13 Acdz w/300 gal 7 ½% NEFE, swab	PLUG AND ABANDON CHANGE PLANS SUBJECT OF THE PLANS SHAPE OF THE PLANS STATE OF THE PLANS SEE RULE 1103. For Multiput Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 1000'. ND BOP. NU tree. Swab test.	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LLING OPNS. P AND A DOB DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON TEMPORARILY ABANDON TO PULL OR ALTER CASING TO THER: 13. Describe proposed or compost of starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 130	PLUG AND ABANDON CHANGE PLANS SUBJECT OF THE PLANS SHAPE OF THE PLANS STATE OF THE PLANS SEE RULE 1103. For Multiput Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 1000'. ND BOP. NU tree. Swab test.	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LLING OPNS. P AND A DOB DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING THER: 13. Describe proposed or compof starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 13 Acdz w/300 gal 7 ½% NEFE, swab	PLUG AND ABANDON CHANGE PLANS SUBJECT OF THE PLANS SHAPE OF THE PLANS STATE OF THE PLANS SEE RULE 1103. For Multiput Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 1000'. ND BOP. NU tree. Swab test.	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LING OPNS. PAND A DESCRIPTION DESCRIPT
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING THER: 13. Describe proposed or compof starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 13 Acdz w/300 gal 7 ½% NEFE, swab	PLUG AND ABANDON CHANGE PLANS SUBJECT OF THE PLANS SHAPE OF THE PLANS STATE OF THE PLANS SEE RULE 1103. For Multiput Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 1000'. ND BOP. NU tree. Swab test.	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LLING OPNS. P AND A DOB DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING THER: 13. Describe proposed or compof starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 13 Acdz w/300 gal 7 ½% NEFE, swab	PLUG AND ABANDON CHANGE PLANS SUBJECT OF THE PLANS SHAPE OF THE PLANS STATE OF THE PLANS SEE RULE 1103. For Multiput Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 1000'. ND BOP. NU tree. Swab test.	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att	ALTERING CASING LLING OPNS. P AND A DOB DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING THER: 13. Describe proposed or compost of starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 130 Acdz w/300 gal 7 ½% NEFE, swab Flow test.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Selected operations. (Clearly state all ork). SEE RULE 1103. For Multiple Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 300'. ND BOP. NU tree. Swab test test. Evaluate	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ole Completions: Att 13096'-98', 13110'-st.	ALTERING CASING LING OPNS. PAND A DESTRUCTION AND A DESTRUCTION AN
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING THER: 13. Describe proposed or compostarting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 130 Acdz w/300 gal 7 ½% NEFE, swab Flow test.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Completed operations. (Clearly state all ork). SEE RULE 1103. For Multiple Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 200'. ND BOP. NU tree. Swab test Evaluate	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att 13096'-98', 13110'-st.	ALTERING CASING LING OPNS. PAND A DISTRICT PAN
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING THER: 13. Describe proposed or compostarting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 130 Acdz w/300 gal 7 ½% NEFE, swab Flow test.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Completed operations. (Clearly state all ork). SEE RULE 1103. For Multiple Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 200'. ND BOP. NU tree. Swab test Evaluate	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att 13096'-98', 13110'-st.	ALTERING CASING LING OPNS. PAND A DESTRUCTION AND A DESTRUCTION AN
PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING THEM. 13. Describe proposed or compostarting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 13 Acdz w/300 gal 7 ½% NEFE, swab Flow test.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Change PLANS MULTIPLE COMPL Change PLANS CHANGE PLA	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att 13096'-98', 13110'- st. pest of my knowledge , a general permit	ALTERING CASING LING OPNS. PAND A DESCRIPTION AND A DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING THER: 13. Describe proposed or compostarting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 130 Acdz w/300 gal 7 ½% NEFE, swab Flow test.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Completed operations. (Clearly state all ork). SEE RULE 1103. For Multiple Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 200'. ND BOP. NU tree. Swab test Evaluate	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att 13096'-98', 13110'-st.	ALTERING CASING LING OPNS. PAND A DESCRIPTION AND A DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING THER: 13. Describe proposed or compost of starting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 130 Acdz w/300 gal 7 ½% NEFE, swab Flow test. I hereby certify that the information grade tank has been/will be constructed or SIGNATURE	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Deleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 200'. ND BOP. NU tree. Swab test test. Evaluate above is true and complete to the best closed according to NMOCD guidelines TITLE	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att 13096'-98', 13110'- st. District Engineer	ALTERING CASING LING OPNS. PAND A DESCRIPTION AND A DESCRIPTION DE
PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING THEM. 13. Describe proposed or compostarting any proposed we or recompletion. 10/24/2007 – 11/25/2007 Kill well w/7% KCL. ND tree. NU RU WL and 5k lub. Set CIBP @ 13 GIH w/CA as pulled. Set pkr @ 13 Acdz w/300 gal 7 ½% NEFE, swab Flow test.	PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPL Deleted operations. (Clearly state all ork). SEE RULE 1103. For Multiple Sk BOP. Rls pkr and POH. 207' and test. Perf Upper Morrow 200'. ND BOP. NU tree. Swab test test. Evaluate above is true and complete to the best closed according to NMOCD guidelines TITLE	REMEDIAL WORK COMMENCE DRIL CASING/CEMENT OTHER: Perf and pertinent details, and ple Completions: Att 13096'-98', 13110'- st. District Engineer	ALTERING CASING LING OPNS. PAND A test Upper Morrow I give pertinent dates, including estimated date ach wellbore diagram of proposed completion 20 20 20 20 20 20 20 20 20 2

APPROVED BY: Law Wind THEE DREPRESENTATIVE II/STAFF MANAGEDATE Conditions of Approval (if any)



Centennial Tower 200 N. Loraine, Suite 1010 Midland, TX 79701 USA 432/683-7063 Fax 432/683-6847

December 7, 2007

State of New Mexico District I 1625 N. French Dr. Hobbs, NM 88240

RE: Eagle 2 State #1

30-025-37453 Lea County, NM



Ladies/Gentlemen:

Form C-103 subsequent report of work performed to perf and test Upper Morrow in the reference well is enclosed.

If you have further questions, please contact the engineer on this project, Mr. Ken Krawietz, (432) 683-7063.

Sincerely,

R. M. Burditt

Sr. Engineering Tech

Enc.