

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr , Hobbs, NM 88240
District II
✓ 301 W. Grand Ave , Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

S OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-29825 ✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG 6638
7. Lease Name or Unit Agreement Name Barr H State ✓
8. Well Number 1 ✓
9. OGRID Number 21355 ✓
10. Pool name or Wildcat <i>SANJUAL</i> NORTH SANJUAL -PENN

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	
2. Name of Operator SOUTHWEST ROYLATIES, INC.	
3. Address of Operator 6 DESTA DRIVE, STE 2100, MIDLAND, TEXAS 79705	
4. Well Location Unit Letter <u>I</u> : <u>1930</u> feet from the <u>SOUTH</u> line and <u>890</u> feet from the <u>EAST</u> line Section <u>7</u> Township <u>16S</u> Range <u>33E</u> NMPM LEA County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 4262.5' GR	
Pit or Below-grade Tank Application <input type="checkbox"/> or Closure <input type="checkbox"/>	
Pit type _____ Depth to Groundwater _____ Distance from nearest fresh water well _____ Distance from nearest surface water _____	
Pit Liner Thickness: _____ mil Below-Grade Tank: Volume _____ bbls; Construction Material _____	

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Plans are to plug and abandon this well per the attached procedures.

Anticipate plugging and abandonment as soon as approved and dependent on rig availability.
This well is on the NMOCD SI Well Listing.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE *Dawn M. Howard* TITLE Operations Assistant DATE 2/4/08

Type or print name Dawn M. Howard E-mail address: dhoward@claytonwilliams.com Telephone No. 432/688-3267

For State Use Only

APPROVED BY: *Chris Williams* TITLE OC DISTRICT SUPERVISOR/GENERAL MANAGER DATE MAR 18 2008

Conditions of Approval (if any):

See changes to plugging procedure. Call

RECEIVED

FEB 11 2008

HOBBS OCD

P & A Procedure
Barr "H" State Well No. 1
Lea County, New Mexico

1. MIRU Plugging Unit.
2. Unhang well. NU rod Stripper. POOH w/rods and pump.
3. ND Wellhead. NU BOP's. POOH w/2-3/8" tubing.
4. RIH w/5-1/2" CIBP, set CIBP @ 10950'. Dump bail 35' of cement on CIBP.
5. Circulate hole with 9.5 lb per gallon mud. *Plug @ 7950' 255x5 or 100' whichever greater*
6. Perforate 5-1/2" casing @ 4509'. Squeeze 100' plug from 4509' to 4409'.
7. RIH and tag plug. If plug not in place. Repeat step 6.
8. Circ. Hole clean with 9.5 lb per gallon mud. *Plug @ 1550' 255x5 or 100' " "*
9. Perforate 5-1/2" casing @ 501'. Squeeze 100' plug from 501' to 401'.
10. RIH and tag plug. If plug not in place. Repeat step 9.
11. Circulate hole with 9.5 lb per gallon mud.
12. Spot 60' plug from 0' to 60'.
13. Weld on marker as per OCD instructions.
14. Cut off anchors. Fill in cellar and level location.
15. Clean off any junk on location.

SOUTHWEST ROYALTIES

PROJECT Barr H State #1
Proposed PTA

PAGE 1 OF 1
 BY DmR DATE 2-4-08

