State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

	OIL CONSERVA			
DISTRICT I 1625 N. French Dr , Hobbs, NM 88240		St. Francis Dr. NM 87505	WELL API NO. 30-025-05477	
DISTRICT II			5. Indicate Type of Lease	(
1301 W. Grand Ave, Artesia, NM 88210			STATE X	, LEE
DISTRICT III			6. State Oil & Gas Lease No.	
1000 Rio Brazos Rd, Aztec, NM 87410	THE PROPERTY OF THE		7. Lease Name or Unit Agreet	ment Name
	TICES AND REPORTS ON WEI			
(DO NOT USE THIS FORM FOR PE	ROPOSALS TO DRILL OR TO DEEPEN (APPLICATION FOR PERMIT" (Form C-1	01) for such proposals.)	North Hobbs (G/SA) Uni Section 24	
1. Type of Well.	TECATION OR LEAVITY (10111 C.)	ory tot but property	8. Well No. 111	/
Oıl Well	Gas Well Other Inj	ector	9. OGRID No. 157984	
Name of Operator Occidental Permian Ltd.	(7. Odlab 10. 137704	
3 Address of Operator			10. Pool name or Wildcat	Hobbs (G/SA)
HCR 1 Box 90 Denver City, TX	79323			
4. Well Location				
Unit Letter D 330	Feet From The North		t From The West	_ Line
Section 24	Township 18-S	Range 37-F	E NMPM	Lea County
	11. Elevation (Show whether DF, RK 3685' DF	(B, RT GR, etc.)		
Pit or Below-grade Tank Application	or Closure			
Pit Type Depth of Groun	nd Water Distance from n	earest fresh water well	Distance from nearest s	urface water
Pit Liner Thickness mil	Below-Grade Tank: Volume	bbls; Construction Ma	terial	
1.		CNI-ti Depart on	Oth on Data	
12. Chec	ck Appropriate Box to Indicate Na FENTION TO:	ture of Notice, Report, or C	other Data SEQUENT REPORT C	DF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	ALTERIN	Ğ CASING
	CHANGE PLANS	COMMENCE DRILLING OP	. =	ABANDONMENT
TEMPORARILY ABANDON		CASING TEST AND CEMEN		
PULL OR ALTER CASING	Multiple Completion		11 30B	
OTHER: Squeeze/Run liner/Perfo		OTHER.		
13. Describe Proposed or Completed O	perations (Clearly state all pertinent do . For Multiple Completions: Attach w	etails, and give pertinent dates	s, including estimated date of	starting any
proposed work) SEE RULE 1103 1. Kill well. Pull injection equipment	. For Multiple Completions: Atlacti w	velibore diagram of proposed	completion of recompletion.	
	1f			
2. Squeeze all perfs. Drill out and te	nt. est squeeze.		EAGILE	is given
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. 	nt. est squeeze.		eceive	Ď
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. 	est squeeze.		eceive	
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT 	est squeeze.		BOOS VE	
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. 	est squeeze.		BOD V & 1 JUN 1 3 2008	
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT Perforate hole. Acid treat. Run back in hole w/injection equi 	est squeeze. D to surface. pment.		ECENEI 8002 E 1 NUL ARRO CARA	
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT Perforate hole. Acid treat. Run back in hole w/injection equi Test casing and chart for the NMO 	est squeeze. D to surface. pment.		JUN 1 3 2008 OBBS OC	
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT Perforate hole. Acid treat. Run back in hole w/injection equi 	est squeeze. D to surface. pment.		JUN 1 3 2008 OBBS OC	
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT Perforate hole. Acid treat. Run back in hole w/injection equi Test casing and chart for the NMC Return well to injection. 	est squeeze. D to surface. pment. DCD.		OBBS OC	
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT Perforate hole. Acid treat. Run back in hole w/injection equi Test casing and chart for the NMO Return well to injection. I hereby certify that the information above in the part of the part o	est squeeze. D to surface. pment. DCD.	vledge and belief. I further certify	OBBS OC	s has been/will be
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT Perforate hole. Acid treat. Run back in hole w/injection equi Test casing and chart for the NMC Return well to injection. 	est squeeze. D to surface. pment. DCD. s true and complete to the best of my know	or an (attached) alternativ	OBBS OC	has been/will be
 Squeeze all perfs. Drill out and te RIH w/4-1/2" JF liner. Clean out liner. Run CBL/CCL/GR log from PBT Perforate hole. Acid treat. Run back in hole w/injection equi Test casing and chart for the NMC Return well to injection. Thereby certify that the information above a constructed or	est squeeze. D to surface. pment. DCD. s true and complete to the best of my know	_	that any pit or below-grade tank	
2. Squeeze all perfs. Drill out and to 3. RIH w/4-1/2" JF liner. 4. Clean out liner. 5. Run CBL/CCL/GR log from PBT 6. Perforate hole. 7. Acid treat. 8. Run back in hole w/injection equi 9 Test casing and chart for the NMC 10. Return well to injection. I hereby certify that the information above 1 constructed or closed according to NMOCD guideline SIGNATURE	D to surface. Drophent. DCD. s true and complete to the best of my known and general permit	or an (attached) alternativ	that any pit or below-grade tank ye OCD-approved e Associate DA	TE 06/11/2008
2. Squeeze all perfs. Drill out and to 3. RIH w/4-1/2" JF liner. 4. Clean out liner. 5. Run CBL/CCL/GR log from PBT 6. Perforate hole. 7. Acid treat. 8. Run back in hole w/injection equi 9 Test casing and chart for the NMC 10. Return well to injection. I hereby certify that the information above 1 constructed or closed according to NMOCD guideline SIGNATURE	D to surface. Drophent. DCD. s true and complete to the best of my knowns. a general permit	or an (attached) alternative plan TITLE Administrative mendy johnson@oxy.com	that any pit or below-grade tank we OCD-approved Associate DA TELEPHONE No	TE 06/11/2008
2. Squeeze all perfs. Drill out and te 3. RIH w/4-1/2" JF liner. 4. Clean out liner. 5. Run CBL/CCL/GR log from PBT 6. Perforate hole. 7. Acid treat. 8. Run back in hole w/injection equi 9 Test casing and chart for the NMC 10. Return well to injection. I hereby certify that the information above 1 constructed or closed according to NMOCD guideline SIGNATURE TYPE OR PRINT NAME Mendy A.	D to surface. Drophent. DCD. s true and complete to the best of my knowns. a general permit	or an (attached) alternative plan TITLE Administrative	that any pit or below-grade tank we OCD-approved Associate DA TELEPHONE No	TE 06/11/2008
2. Squeeze all perfs. Drill out and te 3. RIH w/4-1/2" JF liner. 4. Clean out liner. 5. Run CBL/CCL/GR log from PBT 6. Perforate hole. 7. Acid treat. 8. Run back in hole w/injection equi 9 Test casing and chart for the NMC 10. Return well to injection. I hereby certify that the information above 1 constructed or closed according to NMOCD guideline SIGNATURE TYPE OR PRINT NAME Mendy A. For State Use Only	D to surface. Drophent. DCD. s true and complete to the best of my knowns. a general permit	or an (attached) alternative plan TITLE Administrative mendy johnson@oxy.com	that any pit or below-grade tank we OCD-approved Associate DA TELEPHONE No	TE 06/11/2008