State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

FILE IN TRIPLICATE	OIL CONSERV	ATION DIVISION		
<u>DISTRICT I</u> 1625 N French Dr. , Hobbs, NM 88240		St. Francis Dr. NM 87505	WELL API NO. 30-025-05499	/
<u>DISTRICT II</u>	,		5. Indicate Type of Lease	
1301 W. Grand Ave, Artesia, NM 88210			STATE X	FEE
DISTRICT III			6. State Oil & Gas Lease No.	
1000 Rio Brazos Rd, Aztec, NM 87410				
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or Unit Agree	ment Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			North Hobbs (G/SA) Unit	
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals.)		Section 25		
1. Type of Well: Oil Well Gas Well Other Injector			8. Well No. 441	
Name of Operator Occidental Permian Ltd.			9. OGRID No. 157984	/
3. Address of Operator			10. Pool name or Wildcat	Hobbs (G/SA)
HCR 1 Box 90 Denver City, T	X 79323			
4. Well Location				/
Unit Letter P : 990	Feet From The South	Fee	et From The East	Line
Section 25	Township 18-S 11. Elevation (Show whether DF, RI	Range 37-	E NMPM	Lea County
	3667' DF	KD, KI OK, Etc.)		
Pit or Below-grade Tank Application or Closure				
Pit Type Depth of Ground Water Distance from nearest fresh water well Distance from nearest surface water				
Pit Liner Thickness mil	Below-Grade Tank: Volume	bbls; Construction Ma	aterial	
12. Che	ck Appropriate Box to Indicate Na		Other Data SEQUENT REPORT O	E.
]		
PERFORM REMEDIAL WORK	PLUG AND ABANDON			
		REMEDIAL WORK	ALTERING	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OP	=	ABANDONMENT
		i	NS. PLUG & A	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OP	NS. PLUG & A	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent decreases)	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates	NS. PLUG & A NT JOB ag pressure s, including estimated date of s	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103	CHANGE PLANS Multiple Completion	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates	NS. PLUG & A NT JOB ag pressure s, including estimated date of s	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU.	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de. For Multiple Completions: Attach w	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates	NS. PLUG & A NT JOB ag pressure s, including estimated date of s	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de. For Multiple Completions: Attach w	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates	NS. PLUG & A NT JOB ag pressure s, including estimated date of s	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C 3. NU BOP. 4. POOH w/tubing and injection equ	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de la For Multiple Completions: Attach work. Pull blanking plug.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed	NS. PLUG & A NT JOB ag pressure s, including estimated date of s	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equals 5. Run back in hole w/130 jts of 2-7/	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de. For Multiple Completions: Attach web. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed	NS. PLUG & A NT JOB ag pressure s, including estimated date of s	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equ 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de. For Multiple Completions: Attach web. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed	PLUG & A NT JOB Ing pressure Institution of recompletion.	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equ 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing.	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach work. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ in end.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed	NS. PLUG & A NT JOB ag pressure s, including estimated date of s	ABANDONMENT X
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equ 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for the sum of the sum o	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach work. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ in end.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed	PLUG & A NT JOB Ing pressure Institution of recompletion.	ABANDONMENT
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equ 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing.	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach work. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ in end.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed	PLUG & A NT JOB Ing pressure Institution of recompletion.	ABANDONMENT X
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equ 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for the sum of the sum o	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach work. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ in end.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed	PLUG & A NT JOB Ing pressure Institution of recompletion.	ABANDONMENT X
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C 3. NU BOP. 4. POOH w/tubing and injection equ 5. Run back in hole w/130 jts of 2-7/ 6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for t 9. RDPU & RU. Clean location.	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed (2)4139'.	PLUG & A NT JOB Ing pressure	ABANDONMENT X Starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equal 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for table 9. RDPU & RU. Clean location. I hereby certify that the information above is	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed (2)4139'.	PLUG & A NT JOB Ing pressure	ABANDONMENT X Starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equal 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for the graph of the set of the s	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates vellbore diagram of proposed of 24139'.	PLUG & A NT JOB Ing pressure	ABANDONMENT X Starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equal 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for table 9. RDPU & RU. Clean location. I hereby certify that the information above is	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach webs. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates wellbore diagram of proposed (2)4139'.	PLUG & A NT JOB Ing pressure	ABANDONMENT X Starting any
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equal 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for the graph of the set of the s	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD.	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates vellbore diagram of proposed of 24139'.	PLUG & A NT JOB Ing pressure Is, including estimated date of secompletion or recompletion. JUN 1 1 2003 That any pit or below-grade tank in the OCD-approved	ABANDONMENT X Starting any has been/will be
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equal 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for tags. RDPU & RU. Clean location. I hereby certify that the information above is constructed or closed according to NMOCD guidelines. SIGNATURE	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD. true and complete to the best of my knowless. , a general permit	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates vellbore diagram of proposed of 24139'. ledge and belief 1 further certify or an (attached) alternative plan TITLE Administrative	PLUG & A NT JOB Ing pressure I	ABANDONMENT X Starting any has been/will be 6 06/10/2008
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. C3. NU BOP. 4. POOH w/tubing and injection equal 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad pin 7. ND BOP/Flange up tubing. 8. Test casing to 640# and chart for tag. RDPU & RU. Clean location. I hereby certify that the information above is constructed or closed according to NMOCD guidelines. SIGNATURE	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD. true and complete to the best of my knowless. , a general permit	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates vellbore diagram of proposed of 24139'. ledge and belief I further certify or an (attached) alternative plan TITLE Administrative mendy_johnson@oxy.com	PLUG & A NT JOB Ing pressure	ABANDONMENT X Starting any has been/will be
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed O proposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. Completed O proposed work) SEE RULE 1103 3. NU BOP. 4. POOH w/tubing and injection equal to see the second proposed work of the second proposed wor	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD. true and complete to the best of my knowless. , a general permit	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates vellbore diagram of proposed of 24139'. ledge and belief I further certify or an (attached) alternative plan TITLE Administrative mendy_johnson@oxy.com	PLUG & A NT JOB Ing pressure	ABANDONMENT X Starting any as been/will be 06/10/2008 806-592-6280 8 2008
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER 13. Describe Proposed or Completed Oproposed work) SEE RULE 1103 1. RUPU & RU. 2. Set blanking plug. Test tubing. Completed Oproposed work) SEE RULE 1103 3. NU BOP. 4. POOH w/tubing and injection equal 5. Run back in hole w/130 jts of 2-7/6. Hydrotest tubing. Replace bad ping. Ropelace b	CHANGE PLANS Multiple Completion perations (Clearly state all pertinent de For Multiple Completions: Attach week. Pull blanking plug. ipment. 8" Duoline 20 tubing. Packer set @ n end. the NMOCD. true and complete to the best of my knowless. , a general permit	COMMENCE DRILLING OP CASING TEST AND CEMEN OTHER: High casin etails, and give pertinent dates vellbore diagram of proposed of 24139'. ledge and belief 1 further certify or an (attached) alternative plan TITLE Administrative	PLUG & A NT JOB Ing pressure	ABANDONMENT X Starting any as been/will be 06/10/2008 806-592-6280 8 2008

0-1000 préssure 0-1000 préssure 3/10/08 25-5- robse 25-441 sér2al # 2619 Calzbrate 3/10/08