٠ •	
Submit 3 Concestion Appropriate Distriction State of New Mexico	Form C-103
Office THE BELL BUT Energy, Minerals and Natural Resources	May 27, 2004
1625 N. French Dr., Hobbs, NM 87240 District II	30-025-10981
District III District III	5. Indicate Type of Lease
1000 Rio Brados Red Azles NV 87410 District IV 1220 S. St. Francis Dr., Santa Fe, NM 87505	STATE X FEE
1220 S. St. Francis or, Sana Fe, NM 87505	6. State Oil & Gas Lease No. B9974
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	7. Lease Name or Unit Agreement Name: Myers Langlie Mattix Unit 🏒
1. Type of Well:	8. Well Number
Oil Well     X     Gas Well     Other       2. Name of Operator     (	9. OGRID Number
OXY USA WTP Limited Partnership $\checkmark$	192463
3. Address of Operator	10. Pool name or Wildcat
P.0. Box 50250 Midland, TX 79710-0250 4. Well Location	Langlie Mattix 7Rvr Qn-GB
	Let 1000
4. Well Location Unit Letter L: 1980 feet from the south line and Section 2 Township 24S Range 37E	1986 feet from the west line
Section 2 Township 24S Range 37E 11. Elevation (Show whether DR, RKB, RT, GR, et	Nivii Ivi County Lea
Pit or Below-grade Tank Application or Closure	
Bit type Depth to Groundwater Distance from nearest fresh water well Distance fresh water well Distance fresh water well Distance fresh water well Distance fresh water well well and	
Pit Liner Thickness:         mil         Below-Grade Tank: Volumebbls; Construction	on Material
12. Check Appropriate Box to Indicate Nature of Notice,	Report or Other Data
	•
<u> </u>	SEQUENT REPORT OF:
NOTICE OF INTENTION TO: SUB PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	•
<u> </u>	ING OPNS. PLUG AND
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ING OPNS. PLUG AND ABANDONMENT
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE       CASING TEST AND	ING OPNS. PLUG AND ABANDONMENT
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB	ALTERING CASING
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach	ALTERING CASING
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3	ALTERING CASING
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion       Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 -	ALTERING CASING
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion       A3- G, 45 - R, Lay down 88 - Jts. 2 3         Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 - x-over, 6 - Jts. 2 3/8" Tbg., 2 3/8 x 5 1/2" TAC w/ 103 jts 1-3/8" TBG. NDB	ALTERING CASING
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion       Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 -	ALTERING CASING
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion       Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 - x-over, 6 - Jts. 2 3/8" Tbg., 2 3/8 x 5 1/2" TAC w/ 103 jts 1-3/8" TBG. NDB 1/2 X 12' pump, RDPU and return well to production.	ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING OPNS. PLUG AND ABANDONMENT  e pertinent dates, including estimated date e pertinent dates, including estimated date wellbore diagram of proposed completion  /8" Tbg., Hole 1 Jts. above SN, Pitted 2.0 SN, x-over, 1 - 2 7/8" Polybore Jt., OP, NUWH. RIH w/ 3/4" rod & 2 X 1-
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion       Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 - x-over, 6 - Jts. 2 3/8" Tbg., 2 3/8 x 5 1/2" TAC w/ 103 jts 1-3/8" TBG. NDB 1/2 X 12' pump, RDPU and return well to production.         1 hereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will be constructed or closed according to NMOCD guidelines, a general permit	ALTERING CASING ALTERING CASING ING OPNS. PLUG AND ABANDONMENT e pertinent dates, including estimated date wellbore diagram of proposed completion /8" Tbg., Hole 1 Jts. above SN, Pitted 2.0 SN, x-over, 1 - 2 7/8" Polybore Jt., OP, NUWH. RIH w/ 3/4" rod & 2 X 1-
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion       San Xa - G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion         Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 - x-over, 6 - Jts. 2 3/8" Tbg., 2 3/8 x 5 1/2" TAC w/ 103 jts 1-3/8" TBG. NDB 1/2 X 12' pump, RDPU and return well to production.         I hereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will be constructed or closed according to NMOCD guidelines, a general permit         SIGNATURE       TITLE       Sr. Regula	ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING ALTERI
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.       5/29-6/3/08         5/29-6/3/08       Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion       Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 - x-over, 6 - Jts. 2 3/8" Tbg., 2 3/8 x 5 1/2" TAC w/ 103 jts 1-3/8" TBG. NDB 1/2 X 12' pump, RDPU and return well to production.         I hereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will be constructed or closed according to NMOCD guidelines, a general permit SIGNATURE	ALTERING CASING ALTERING CASING ING OPNS. PLUG AND ABANDONMENT e pertinent dates, including estimated date wellbore diagram of proposed completion /8" Tbg., Hole 1 Jts. above SN, Pitted 2.0 SN, x-over, 1 - 2 7/8" Polybore Jt., OP, NUWH. RIH w/ 3/4" rod & 2 X 1- e and belief. I further certify that any pit or below- Or an (attached) alternative OCD-approved plan tory Analyst
PERFORM REMEDIAL WORK       PLUG AND ABANDON       REMEDIAL WORK         TEMPORARILY ABANDON       CHANGE PLANS       COMMENCE DRILL         PULL OR ALTER CASING       MULTIPLE COMPLETION       CASING TEST AND CEMENT JOB         OTHER:       OTHER:       OTHER:         13. Describe proposed or completed operations. (Clearly state all pertinent details, and giv of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.         5/29-6/3/08         Tbg-0 # Csg-25# - RUPU, POOH w/ rods & pump. NDWH, NUBOP         Scan TBg. Out of Hole, 0 - YB, 33- B, 43- G, 45 - R, Lay down 88 - Jts. 2 3 Corrosion         Make Up 2 3/8" Bull Plug, 1 - Jt. 2 3/8" Tbg. MA, 1 - 4' 2 3/8" Perf. sub, 1 - x-over, 6 - Jts. 2 3/8" Tbg., 2 3/8 x 5 1/2" TAC w/ 103 jts 1-3/8" TBG. NDB 1/2 X 12' pump, RDPU and return well to production.         I hereby certify that the information above is true and complete to the best of my knowledge grade tank bas been/will be constructed or closed according to NMOCD guidelines, a general permit         SIGNATURE       TITLE	ALTERING CASING ALTERING CASING ING OPNS. PLUG AND ABANDONMENT e pertinent dates, including estimated date wellbore diagram of proposed completion /8" Tbg., Hole 1 Jts. above SN, Pitted 2.0 SN, x-over, 1 - 2 7/8" Polybore Jt., OP, NUWH. RIH w/ 3/4" rod & 2 X 1-