Submit 3 Copies To Appropriate District State of New Mexico Office Energy, Minerals and Natural Resources	Form C-103
District I District Grant Grant	May 27, 2004
1625 N. French Dr., Hobbs NM 8/240 / 1118	WELL API NO.
District II OH CONCEDIATION DIVICION	30-025-36090
1301 W. Grand Ave., Artesia NM 88210 District III 1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505	STATE 🗷 FEE 🗌 🥏
District IV. 1220 S. St. Francis Dr., Santa Fe, NM 87505	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name:
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	San Simon State 21
PROPOSALS.)	
1. Type of Well:	8. Well Number
Oil Well Gas Well X Other	1
2. Name of Operator	9. OGRID Number
EOG Resources Inc.	7377
3. Address of Operator	10. Pool name or Wildcat
P.O. Box 2267 Midland, Texas 79702	Osudo; Morrow, South (Gas)
4. Well Location	
Unit Letter H : 1864 feet from the North line and	838 feet from the East line
Section 21 Township 21s Range 35E	NMPM County Lea
11. Elevation (Show whether DR, RKB, RT, GR,	
3610 GR	
Pit or Below-grade Tank Application or Closure	
Pit type Depth to Groundwater Distance from nearest fresh water well	Distance from nearest surface water
Pit Liner Thickness: mil Below-Grade Tank: Volumebbls; Construc	` ·
The Line Time Time Time Time Time Time Time Tim	
12. Check Appropriate Box to Indicate Nature of Notice NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	BSEQUENT REPORT OF:
TEMPORARILY ABANDON	
	LING OPNS. PLUG AND ABANDONMENT
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ive pertinent dates, including estimated date
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D plug AND ABANDONMENT ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab.
TEMPORARILY ABANDON	PLUG AND ABANDONMENT D PLUG AND ABANDONMENT ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water.
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. . SDFN
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. . SDFN
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. . SDFN
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. . SDFN
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. . SDFN
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL PULL OR ALTER CASING MULTIPLE CASING TEST AN CEMENT JOB OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and go f starting any proposed work). SEE RULE 1103. For Multiple Completions: Atta or recompletion. 12/15/08 MIRU swab unit in attempt to re-establish production. Bl Make 4 runs swabbing down to 12,100 (Morrow Perfs 12367 - Wait 2 hrs. Make 2 more swab runs recovering 3 bbls water. 12/16/08 RIH and make 3 swab runs. Recovered 6 bbls water. Wait 2 one every 2 hrs. Recovered 12 bbls water. Left well open to sales pending workover.	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT Dive pertinent dates, including estimated date ch wellbore diagram of proposed completion Ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. SDFN hrs. Made 4 more swab runs,
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT Dive pertinent dates, including estimated date ch wellbore diagram of proposed completion Ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. SDFN hrs. Made 4 more swab runs,
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D ABANDONMENT Dive pertinent dates, including estimated date ch wellbore diagram of proposed completion Ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. SDFN hrs. Made 4 more swab runs,
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT PLUG AND ABANDONMENT D ive pertinent dates, including estimated date ch wellbore diagram of proposed completion ow down tubing. RIH w/ swab. 12378) recovering 7 bbls water. SDFN hrs. Made 4 more swab runs, ge and belief. I further certify that any pit or belowit or an (attached) alternative OCD-approved plan
PULL OR ALTER CASING	LING OPNS. PLUG AND ABANDONMENT D A
TEMPORARILY ABANDON	LING OPNS. PLUG AND ABANDONMENT D A