Submit 3 Copies To Appropriate District State of New Mexico Office Energy, Minerals and Natural Resources	Form C-103
District 1 Energy, Minerals and Natural Resources	WELL API NO.
District II	30-025-21821
District III 1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd , Aztec, NM 87410 District IV Santa Fc, NM 87505	STATE     FEE     XX       6. State Oil & Gas Lease No.
1220 S St Francis Dr., Santa Fe, NM	
87505 SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-201) FOR SUCH PROPOSALS.)	Eidson "A" WN
1. Type of Well: Oil Well 🗽 Gas Well 🔲 Other	8. Well Number 4
2. Name of Operator Primero Operating, Inc. /	9. OGRID Number
3. Address of Operator	018100   10. Pool name or Wildcat
PO Box 1433, Roswell, NM 88202-1433	Shoebar WC & Townsend Abo
4. Well Location	
Unit Letter_Kfeet from the South line and 17	/
Section 26 Township 16S Range 35E	NMPM County Lea
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3966 Gr	
12. Check Appropriate Box to Indicate Nature of Notice,	Report or Other Data
	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON XX REMEDIAL WOR	
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRI PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMEN	
OTHER: OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date	
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion $FSOH$ or recompletion. We propose to plug this well as follows: TAG CIBP & Dump Bail 35'	
$\alpha = 10$	11.00
We propose to plug this well as follows: TAG CIBP & Dump Bail 35.	18001 (Top or a
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Pe	rforate squeeze hole at 6284', 4850', 466', and 60'
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Pe Circulate hole w/ 9# mud (9.5 ppg brine w/12.5 # salf gel per bbl) Bet Bump 35 av account also @ 5284 and account is and what 55 400 with the safe for the bold of the safe for the safe f	rforate squeeze hole at 6284', 4850', 466', and 60' wm Plugs
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Pe Circulate hole w/ 9# mud (9.5 ppg brine w/12.5 # salf gel per bbl) Bet Bump 35 av account also @ 5284 and account is and what 55 400 with the safe for the bold of the safe for the safe f	rforate squeeze hole at 6284', 4850', 466', and 60' wm Plugs
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 pg brine w/12.5 # salf gel per bbl) Bed Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing, Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing, Tag this plug	inforate squeeze hole at 6284', 4850', 466', and 60' $W \sim Plugs$ $P 1800'. 5 \varphi w/35 sx. Wo C = TAG.$
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 $\rho$ G brine w/12.5 # salf gel per bbl) Bed Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing	$P_{1800}^{\prime}$ 50 w/355X. WOC - 74G,
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rhog)$ brive $w/12.5 \#$ salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 486' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula	inforate squeeze hole at 6284', 4850', 466', and 60' www Plugs $P 1800'. 5 \varphi w/35sx. Woz = TAG,$ JUN 15 20()9 HOPPEOCO
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 pg brive w/12.5 # Salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.)	The provided at 6284', 4850', 466', and 60' WW Plugs P 1800'. $S \phi w/_{35} sx \cdot w_{02} + TAG,$ JUN 15 2009 HOBBSOCD
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 pg brive w/12.5 # Salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.)	The provided at 6284', 4850', 466', and 60' WW Plugs P 1800'. $S \phi w/_{35} sx \cdot w_{02} + TAG,$ JUN 15 2009 HOBBSOCD
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 pg brive w/12.5 # Salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.)	The provided at 6284', 4850', 466', and 60' WW Plugs P 1800'. $S \phi w/_{35} sx \cdot w_{02} + TAG,$ JUN 15 2009 HOBBSOCD
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 pg brive w/12.5 # Salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.)	The provided at 6284', 4850', 466', and 60' WW Plugs P 1800'. $S \phi w/_{35} sx \cdot w_{02} + TAG,$ JUN 15 2009 HOBBSOCD
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 pg brive w/12.5 # Salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.)	inforate squeeze hole at 6284', 4850', 466', and 60' www Plugs $P 1800'. 5 \varphi w/35sx. Woz = TAG,$ JUN 15 20()9 HOPPEOCO
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rho g \land w w/12.5 \# salf gel per bbl)$ Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC $47AG$ Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Perf @ Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ $41b'$ (Circ.) $8^{5}/8' CSG$ @ $4800'$ (ToC $3070'$ T.S.) $5^{1}/2'' cSG$ @ $10,431'$ (ToC $8020'$ T.S.) Spud Date: $7/14/1966$ Rig Release Date: $8/22/1966$	tions. HOBBSOCD HOBBSOCD HOBBSOCD Hobbsocn Hobbsoc
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 pg brive w/12.5 # Salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.)	tions. HOBBSOCD HOBBSOCD HOBBSOCD Hobbsocn Hobbsoc
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud (9.5 ppg brive w/12.5 # salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Perf @ Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Perf @ Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Perf @ Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Perf @ Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.) $8^{5}/8' CSG @ 4800' (TOC 3070' T.S.)$ $5^{1}/2'' CSG @ 10,431' (ToC 8020' T.S.)$ Spud Date: 7/14/1966 I hereby certify that the information above is true and complete to the best of my knowledged	where $Plugs$ P 1800. $S \phi w/35sx$ . $woc : TAG$ , JUN 15 20(19) tions. HOBBSOCD Prior to the beginning of plugging operations and belief.
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rho g \land w w/12.5 \# salf gel per bbl)$ Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC $47AG$ Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Perf @ Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ $41b'$ (Circ.) $8^{5}/8' CSG$ @ $4800'$ (ToC $3070'$ T.S.) $5^{1}/2'' cSG$ @ $10,431'$ (ToC $8020'$ T.S.) Spud Date: $7/14/1966$ Rig Release Date: $8/22/1966$	tions. HOBBSOCD HOBBSOCD HOBBSOCD Hobbsocn Hobbsoc
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circutate hole w/ 9# mud (9.5 ppg brive w/12.5 # salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC #TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^3/4$ (CSG @ 416' (Circ.) 85/8 (CSG @ 4800' (TOC 3070' T.S.) $5^1/2$ '' CSG @ 10,431' (ToC 8020' T.S.) Spud Date: 7/14/1966 The certify that the information above is true and complete to the best of my knowledge SIGNATURE Type or print name Phelps White Type or print name Phelps White Start of the phelps White Phelps White Type or print name Phelps White Type or print name Phelps White Type or print name Phelps White	riforate squeeze hole at 6284', 4850', 466', and 60' WWW Plugs P 1800. SQ w/3555X. WOC TAG, JUN 15 20()9 tions. HOBBSOCD Prior to the beginning of plugging operations e and belief. DATE June 11, 2009
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circutate hole w/ 9# mud (9.5 ppg brive w/12.5 # salf gel per bbl) Bet Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC #TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 26 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ 416' (Circ.) 85/8' CSG @ 4800' (ToC 3070' T.S.) $5^{1/2}$ '' CSG @ 10,431' (ToC 8020' T.S.) Spud Date: 7/14/1966 I hereby certify that the information above is true and complete to the best of my knowledge SIGNATURE SIGNATURE TITLE President	riforate squeeze hole at 6284', 4850', 466', and 60' WWW Plugs P 1800. SQ w/3555X. WOC TAG, JUN 15 20()9 tions. HOBBSOCD Prior to the beginning of plugging operations e and belief. DATE June 11, 2009
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rho g)$ brine w/12.5 # salf gel per bb/) Bed Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 4866' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 36 brine will be bed and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ $41b'$ (Circ.) $8^{5}/8'$ CSG @ $4800'$ (ToC $3070'$ T.S.) $5^{1}/2''$ CSG @ $10, 431'$ (ToC $8020'$ T.S.) Spud Date: $7/14/1966$ Rig Release Date: $8/22/1966$ I hereby certify that the information above is true and complete to the best of my knowledged SIGNATURE Type or print name Phelps White For State Use Only APPROVED BY: Mathematical brief	riforate squeeze hole at 6284', 4850', 466', and 60' WWW Plugs P 1800. SQ w/3555X. WOC TAG, JUN 15 20()9 tions. HOBBSOCD Prior to the beginning of plugging operations e and belief. DATE June 11, 2009
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rho g)$ by inc w/12.5 # salf gel per bb/) Bed Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing W0C # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 25 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^3/4$ , CSG @ 416' (Circ.) 85/8'CSG @ 4800' (ToC 3070'T.S.) $5^1/2'' CSG @ 10,431' (ToC 8020'T.S.)$ Spud Date: 7/14/1966 I hereby certify that the information above is true and complete to the best of my knowledge SIGNATURE Type or print name Phelps White For State Use Only For State Use Only	Iforate squeeze hole at 6284', 4850', 466', and 60'     www.Plugs     P 1800'. S φ w/355SX. WOC - TAG,     JUN 15 2009     Itions.     HOBBSOCD     Inservation Division Must be notified     prior to the beginning of plugging operations     e and belief.     DATE June 11, 2009     pm     PHONE: 575 626 7660
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rho g)$ brine w/12.5 # salf gel per bb/) Bed Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 4866' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 36 brine will be bed and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ $41b'$ (Circ.) $8^{5}/8'$ CSG @ $4800'$ (ToC $3070'$ T.S.) $5^{1}/2''$ CSG @ $10, 431'$ (ToC $8020'$ T.S.) Spud Date: $7/14/1966$ Rig Release Date: $8/22/1966$ I hereby certify that the information above is true and complete to the best of my knowledged SIGNATURE Type or print name Phelps White For State Use Only APPROVED BY: Mathematical brief	Iforate squeeze hole at 6284', 4850', 466', and 60'     www.Plugs     P 1800'. S φ w/355SX. WOC - TAG,     JUN 15 2009     Itions.     HOBBSOCD     Inservation Division Must be notified     prior to the beginning of plugging operations     e and belief.     DATE June 11, 2009     pm     PHONE: 575 626 7660
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rho g)$ brine w/12.5 # salf gel per bb/) Bed Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 4866' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 36 brine will be bed and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ $41b'$ (Circ.) $8^{5}/8'$ CSG @ $4800'$ (ToC $3070'$ T.S.) $5^{1}/2''$ CSG @ $10, 431'$ (ToC $8020'$ T.S.) Spud Date: $7/14/1966$ Rig Release Date: $8/22/1966$ I hereby certify that the information above is true and complete to the best of my knowledged SIGNATURE Type or print name Phelps White For State Use Only APPROVED BY: Mathematical brief	Iforate squeeze hole at 6284', 4850', 466', and 60'     www.Plugs     P 1800'. S φ w/355SX. WOC - TAG,     JUN 15 2009     Itions.     HOBBSOCD     Inservation Division Must be notified     prior to the beginning of plugging operations     e and belief.     DATE June 11, 2009     pm     PHONE: 575 626 7660
Dump 35' cement on top of CIBP @ 9650', set new CIBP @ 8600' and dump 35' cement on top. Per Circulate hole w/ 9# mud $(9.5 \rho g)$ brine w/12.5 # salf gel per bb/) Bed Pump 35 sx cement plug @ 6284 and squeeze in and out of 5 1/2" casing WOC # TAG Pump 35 sx cement plug @ 4850 and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 4866' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 35 sx cement plug @ 466' and squeeze in and out of 5 1/2" casing. Tag this plug Pump 36 brine will be bed and squeeze in and out of 5 1/2" casing. Tag this plug Pump cement @ 60' to fill hole inside and out of 5 1/2" casing A dry hole marker will be set. and the lease will be cleared of equipment and junk to NMOCD regula $11^{3}/4$ CSG @ $41b'$ (Circ.) $8^{5}/8'$ CSG @ $4800'$ (ToC $3070'$ T.S.) $5^{1}/2''$ CSG @ $10, 431'$ (ToC $8020'$ T.S.) Spud Date: $7/14/1966$ Rig Release Date: $8/22/1966$ I hereby certify that the information above is true and complete to the best of my knowledged SIGNATURE Type or print name Phelps White For State Use Only APPROVED BY: Mathematical brief	Iforate squeeze hole at 6284', 4850', 466', and 60'     www.Plugs     P 1800'. S φ w/355SX. WOC - TAG,     JUN 15 2009     Itions.     HOBBSOCD     Inservation Division Must be notified     prior to the beginning of plugging operations     e and belief.     DATE June 11, 2009     pm     PHONE: 575 626 7660