Submit I Copy To Appropriate District	State	of New Me			Form C-1
Office District I	Energy, Minera	als and Natu	ral Resources	WELL API NO.	October 13, 2
1625 N French Dr , Hobbs, NM 88240 District II		DALA TION	DIMEION	30-025-39377	/
1301 W Grand Ave , Artesia, NM/882	ECEIWE BONSE	KVAHUN	DIVISION	5. Indicate Type of	
District III 1000 Rio Brazos Rd , Aztec, NM 87410 District IV	1220 SO	uth St. Fran Fe, NM 87		STATE STATE	
District IV  1220 S. St. Francis Dr. Santa Fe. NM	rn Gu Luiu Sania	1 1 °C, INIVI 0 /	505	6. State Oil & Gas	s Lease No.
1220 S St Francis Dr , Santa Fe, NM 87505	)RR20CD				***
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			7. Lease Name or LANGLEY 21 CC	· Unit Agreement Nam	
DIFFERENT RESERVOIR. USE "AP	PLICATION FOR PERMIT" (F	FORM C-101) FO	OR SUCH	LANGLET 21 CC	)W1
PROPOSALS.)  1. Type of Well: Oil Well	Gas Well 🛛 Other			8. Well Number (	001
<ol> <li>Type of Well: Oil Well</li> <li>Name of Operator</li> </ol>	das well 🔼 Other			9. OGRID Numbe	er ,
NADEL AND GUSSMAN PER	RMIAN, LLC			155615	
3. Address of Operator			10. Pool name or		
601 N MARIENFELD, STE. 508 MIDLAND, TX 79701				WILDCAT MORE	ROW -
4. Well Location				0 0	D. 1.072
	80feet from theNOR		ne and800	feet from the	EAST line
Section 21	Township 23S  11. Elevation (Show	Range		NMPM LEA C	ounty V
	11. Elevation (Snow	v wneiner DK,	KKD, $KI$ , $GK$ , $e$	ic.)	
				Longitude American Control of the Co	
12. Chec	k Appropriate Box to	Indicate N	ature of Notic	e, Report or Other	Data
	• • • • • • • • • • • • • • • • • • • •			_	
	INTENTION TO:		SU REMEDIAL WO	JBSEQUENT REF	PORT OF: ALTERING CASING
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	<ul><li>☐ PLUG AND ABAND</li><li>☐ CHANGE PLANS</li></ul>	ON [			P AND A
PULL OR ALTER CASING	☐ MULTIPLE COMPL		CASING/CEME		FANDA
		. Ц	CAGING/OLIVIL	111 000	
BOTTH TOLL COMMITTEL					
		_	_		
OTHER:			OTHER:	and since of data	- including actimated
13. Describe proposed or co	ompleted operations. (Cle	early state all p	pertinent details,	and give pertinent date	es, including estimated
13. Describe proposed or co	work). SEE RULE 19.1:	early state all p	pertinent details,	and give pertinent date Completions: Attach w	es, including estimated rellbore diagram of
13. Describe proposed or co	work). SEE RULE 19.1:	early state all p	pertinent details,	and give pertinent date Completions: Attach w	es, including estimated rellbore diagram of
13. Describe proposed or co of starting any proposed proposed completion or	I work). SEE RULE 19.1: recompletion.	5.7.14 NMAC	pertinent details, and the control of the control o	Completions: Attach w	s, including estimated ellbore diagram of
13. Describe proposed or co	work). SEE RULE 19.1. recompletion. 754' – DUMP 35' OF CEMEN	5.7.14 NMAC T ON TOP – CII	pertinent details, continent det	Completions: Attach w	s, including estimated ellbore diagram of
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57	1 work). SEE RULE 19.1. recompletion. 754' – DUMP 35' OF CEMEN 00# - SPOT 25 SACKS @ 56	5.7.14 NMAC T ON TOP – CII	pertinent details, continent det	Completions: Attach w	s, including estimated rellbore diagram of
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100' 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PI	I work). SEE RULE 19.1. recompletion. 754' – DUMP 35' OF CEMEN 00# - SPOT 25 SACKS @ 56 - ULL 3000' OF CASING – SPO	5.7.14 NMAC T ON TOP – CII 500' – TAG @ 5	pertinent details, continent det	Completions: Attach w SING MUD 2914' –	vellbore diagram of
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100' 3/17/10 SPOT 25 SACKS @ 3900'	I work). SEE RULE 19.1. recompletion. 754' – DUMP 35' OF CEMEN 00# - SPOT 25 SACKS @ 56 - ULL 3000' OF CASING – SPO	5.7.14 NMAC T ON TOP – CII 500' – TAG @ 5	pertinent details, continent det	Completions: Attach w SING MUD 2914' –	vellbore diagram of
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100' 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PI 3/19/10 PERF @ 1300' – HELD 80	d work). SEE RULE 19.1: recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130	5.7.14 NMAC T ON TOP – CII 600' – TAG @ 5: OT 35 SACKS @ 00' – PERF @ 4	pertinent details, in the continuous pertinent details pertine	Completions: Attach w SING MUD 2914' – - SPOT 45 SACKS @ 500	vellbore diagram of 0' – TAG @ 345'
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100' 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PI	d work). SEE RULE 19.1: recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130	5.7.14 NMAC T ON TOP – CII 600' – TAG @ 5: OT 35 SACKS @ 00' – PERF @ 4	pertinent details, in the continuous pertinent details pertine	Completions: Attach w SING MUD 2914' – - SPOT 45 SACKS @ 500	vellbore diagram of 0' – TAG @ 345'
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - Pt 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE	d work). SEE RULE 19.1: recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE	5.7.14 NMAC T ON TOP – CII 500' – TAG @ 5: OT 35 SACKS @ 00' – PERF @ 4	Dertinent details, 2. For Multiple Control of Control o	Completions: Attach w SING MUD  2914' – - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAR	vellbore diagram of  0' – TAG @ 345'  RKER - LEVEL LOCATIO
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 10 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - Pt 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE	d work). SEE RULE 19.1: recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE	5.7.14 NMAC T ON TOP – CII 600' – TAG @ 5: OT 35 SACKS @ 00' – PERF @ 4	pertinent details, c. For Multiple C. RCULATE PLUGG 351  @ 3050' – TAG @ 2450" – HELD 800#  LL HEAD AN ANCI	Completions: Attach w  SING MUD  2914' SPOT 45 SACKS @ 500  HORS - INSTALL PA MAF  coved for plugging of well bor  clity under bond is retained p	ovellbore diagram of  0' – TAG @ 345'  RKER - LEVEL LOCATION  re only,  pending receipt
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 10 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - Pt 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE	d work). SEE RULE 19.1: recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE	5.7.14 NMAC T ON TOP – CII 500' – TAG @ 5: OT 35 SACKS @ 00' – PERF @ 4	Dertinent details, 2. For Multiple C  RCULATE PLUGG 3551	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAP  roved for plugging of well bor fility under bond is retained p 103 (Subsequent Report of Y h may be found at OCD Web	ovellbore diagram of  O' – TAG @ 345'  RKER - LEVEL LOCATION  TE only,  Dending receipt  Well Plugging)  De Page under
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PI 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE	I work). SEE RULE 19.1. recompletion.  754' – DUMP 35' OF CEMENT 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE	5.7.14 NMAC T ON TOP – CII 500' – TAG @ 55 OT 35 SACKS @ 00' – PERF @ 4 - CUT OFF WE	Dertinent details, 2. For Multiple Control Multiple Contr	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAP  roved for plugging of well bor  litty under bond is retained p  103 (Subsequent Report of V  h may be found at OCD Web  18, www.emnrd.state.nmi.us/pg	ovellbore diagram of  O' – TAG @ 345'  RKER - LEVEL LOCATION  TE only,  Dending receipt  Well Plugging)  De Page under
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100' 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PI 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE	I work). SEE RULE 19.1. recompletion.  754' – DUMP 35' OF CEMENT 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE	5.7.14 NMAC T ON TOP – CII 500' – TAG @ 55 OT 35 SACKS @ 00' – PERF @ 4 - CUT OFF WE	Dertinent details, 2. For Multiple Control Multiple Contr	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAP  roved for plugging of well bor  litty under bond is retained p  103 (Subsequent Report of V  h may be found at OCD Web  18, www.emnrd.state.nmi.us/pg	ovellbore diagram of  O' – TAG @ 345'  RKER - LEVEL LOCATION  TE only,  Dending receipt  Well Plugging)  De Page under
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 100 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PI 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE	d work). SEE RULE 19.1. recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 100# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE  R  Aon above is true and com	5.7.14 NMAC  T ON TOP – CII  600' – TAG @ 5:  OT 35 SACKS @  00' – PERF @ 4  - CUT OFF WE  tig Release Da	Dertinent details, 2. For Multiple Control of Control o	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAF  roved for plugging of well bor  litty under bond is retained p  103 (Subsequent Report of Y h may be found at OCD Web  18, www.cmird.state.fim.us/or  rodge and belief.	o' – TAG @ 345'  RKER - LEVEL LOCATION  re only,  pending receipt  Well Plugging)  Page under  sed:
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 10/3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - Pt 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE Spud Date:	d work). SEE RULE 19.1. recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 100# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE  R  Aon above is true and com	5.7.14 NMAC  T ON TOP – CII  600' – TAG @ 5:  OT 35 SACKS @  00' – PERF @ 4  - CUT OFF WE  tig Release Da	Dertinent details, 2. For Multiple Control of Control o	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAF  roved for plugging of well bor  litty under bond is retained p  103 (Subsequent Report of Y h may be found at OCD Web  18, www.cmird.state.fim.us/or  rodge and belief.	o' – TAG @ 345'  RKER - LEVEL LOCATION  re only,  pending receipt  Well Plugging)  Page under  sed:
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 10/3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - Pt 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE Spud Date:	d work). SEE RULE 19.1. recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 100# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE  R  Aon above is true and com	5.7.14 NMAC  T ON TOP – CII  600' – TAG @ 5:  OT 35 SACKS @  00' – PERF @ 4  - CUT OFF WE  tig Release Da	Dertinent details, 2. For Multiple Control of Control o	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAF  roved for plugging of well bor  litty under bond is retained p  103 (Subsequent Report of Y h may be found at OCD Web  18, www.cmird.state.fim.us/or  rodge and belief.	o' – TAG @ 345'  RKER - LEVEL LOCATION  re only,  pending receipt  Well Plugging)  Page under  sed:
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 10' 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE Spud Date:	d work). SEE RULE 19.1. recompletion.  754' – DUMP 35' OF CEMEN' 00# - SPOT 25 SACKS @ 56  - ULL 3000' OF CASING – SPO 100# - SPOT 45 SACKS @ 130 E 45 SACKS TO SURFACE  R  Aon above is true and com	5.7.14 NMAC  T ON TOP – CII  600' – TAG @ 5:  OT 35 SACKS @  00' – PERF @ 4  - CUT OFF WE  tig Release Da	Dertinent details, 2. For Multiple Control of Control o	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAP  roved for plugging of well bor  litty under bond is retained p  103 (Subsequent Report of V  h may be found at OCD Web  18, www.emnrd.state.nmi.us/pg	o' – TAG @ 345'  RKER - LEVEL LOCATION  re only,  pending receipt  Well Plugging)  Page under  sed:
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 10' 3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - PI 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE Spud Date:	work). SEE RULE 19.1. recompletion.  254' – DUMP 35' OF CEMENT 00# - SPOT 25 SACKS @ 56  ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130  E 45 SACKS TO SURFACE  R  Aon above is true and com  The Skins E	5.7.14 NMAC T ON TOP – CII 500' – TAG @ 55 OT 35 SACKS @ 00' – PERF @ 4 - CUT OFF WE aig Release Da TITLE	Dertinent details, 2. For Multiple Control of Control o	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAP  roved for plugging of well bor fility under bond is retained p 103 (Subsequent Report of V h may be found at OCD Web  in www.emirtd.state.filin.us/pordige and belief.  DA  DA  DD MARYS. Net PHO  DA	vellbore diagram of  0' – TAG @ 345'  RKER - LEVEL LOCATION  re only, pending receipt  Well Plugging) p Page under  sed:  ATE 4-23-20
13. Describe proposed or co of starting any proposed proposed completion or 3/12/10 RIH WITH CIBP SET @ 57 3/16/10 PERF @ 5550' – HELD 10/3/17/10 SPOT 25 SACKS @ 3900' 3/18/10 CUT CASING @ 3000' - Pt 3/19/10 PERF @ 1300' – HELD 80 3/22/10 PERF @ 60' – CIRCULATE Spud Date:	work). SEE RULE 19.1. recompletion.  254' – DUMP 35' OF CEMENT 00# - SPOT 25 SACKS @ 56  ULL 3000' OF CASING – SPO 00# - SPOT 45 SACKS @ 130  E 45 SACKS TO SURFACE  R  Aon above is true and com  The Skins E	5.7.14 NMAC  T ON TOP – CII  600' – TAG @ 5:  OT 35 SACKS @  00' – PERF @ 4  - CUT OFF WE  tig Release Da	Dertinent details, 2. For Multiple Control of Control o	Completions: Attach w  SING MUD  2914' — - SPOT 45 SACKS @ 500  HORS - INSTALL PA MAF  roved for plugging of well bor  litty under bond is retained p  103 (Subsequent Report of Y h may be found at OCD Web  18, www.cmird.state.fim.us/or  rodge and belief.	vellbore diagram of  0' – TAG @ 345'  RKER - LEVEL LOCATION  re only, pending receipt  Well Plugging) p Page under  sed:  ATE 4-23-20