

Submit 1 Copy To Appropriate District Office
 District I
 1625 N French Dr., Hobbs, NM 88240
 District II
 1301 W. Grand Ave., Artesia, NM 88210
 District III
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV
 1220 S. St. Francis Dr., Santa Fe, NM 87505

RECEIVED State of New Mexico
 Energy, Minerals and Natural Resources
 JUL 19 2010
 OIL CONSERVATION DIVISION
 220 South St. Francis Dr.
 Santa Fe, NM 87505

Form C-103
 October 13, 2009

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)		WELL API NO. <u>30-025-24287</u> ✓
1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐		5. Indicate Type of Lease STATE ☒ FEE ☐
2. Name of Operator <u>DC ENERGY LLC</u>		6. State Oil & Gas Lease No. <u>306783</u>
3. Address of Operator <u>105 OSCAR LANE DALLAS GA 30132</u>		7. Lease Name or Unit Agreement Name <u>Crosby Gregory</u>
4. Well Location Unit Letter <u>G</u> : <u>25</u> feet from the <u>SE</u> line and <u>2310</u> feet from the <u>EAST</u> line Section <u>33</u> Township <u>25S</u> Range <u>37E</u> NMPM County <u>LEA</u>		8. Well Number # <u>2</u>
11. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. OGRID Number <u>268370</u> ✓
10. Pool name or Wildcat <u>Crosby Russelman</u>		

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐
 TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
 PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
 DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
 COMMENCE DRILLING OPNS ☐ P AND A ☐
 CASING/CEMENT JOB ☒

OTHER: SQ CS9 + TEST (CBL) ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- To Do Squeeze Job on ABOVE well as ordered by OGD from permit SWD 240-A-B. (PLEASE SEE BELOW)*
- 1) Remove TBG FROM well
 - 2) INSTALL RBP WITH 10' SAND AT 6,000'
 - 3) RUN WIRE LINE, Correlate to prev logs, perforate Squeeze zone at 5100' (SAN ADREAS zone 3900'-4682')
 - 4) RIT W PACKER/TAIPIPE (PACKER @ 5800', TAILPIPE @ 5080') INJECTION RATE
 - 5) Rig up cement pump truck
 - 6) inject 250 sacks of cement with 2% C.C.
 - 7) Displace Cement TO END OF TAILPIPE Below Packer, static Cement Give

Spud Date:

Rig Release Date:

- 8) Let Cement Cure min 8 hrs 9) Pull W TBG/PKR 10) Test Squeeze, Seal

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

DATE

Type or print name

E-mail address:

PHONE:

For State Use Only

APPROVED BY:

TITLE

DATE

Conditions of Approval (if any):

Schematic Well Bore Casing Deep #2

UL-G Sec. 33, T25S, R37E 1650'FWL 2910'FEL Oil Well
LEA COUNTY, N.M.
DC ENERGY LLC. Producing

