

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised June 10, 2003

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-005-20495
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other ☐

7. Lease Name or Unit Agreement Name
Robert H. Hannifin

8. Well Number
#1

2. Name of Operator
HANSON OPERATING COMPANY, INC.

9. OGRID Number
009974

3. Address of Operator
P. O. Box 1515, Roswell, New Mexico 88202-1515

10. Pool name or Wildcat
Wildcat San Andres

4. Well Location

Unit Letter **C** : **660** feet from the **North** line and **1980** feet from the **West** line

Section **31** Township **9 South** Range **30 East** NMPM **Chaves** County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
4010' GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

02/04/2004: RU. TIH with tubing to 3306'. Set 25 sack cement plug at 3306'. WOC 2 hours. Tag top of cement at 3200'. Circulate with salt water gel. Perf 2 holes at 1487'. Set 25 sack cement plug at 1487'. WOC 2 hours. Tag top of cement at 1300'. Perf 2 holes at 350'. Set 40 sack cement plug at 350'. WOC 2 hours. Tag top of cement at 200'. Perf 2 holes at 60'. Set cement plug at 60' to Surface. Circulate 4 sacks cement to pit. Well is plugged and abandoned.

02/05/2004: Fill pit, cut anchors and install Dry Hole Marker. Location reclaimed and finalized.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Carol J. Garcia TITLE Production Analyst DATE 02/09/2004

Type or print name Carol J. Garcia E-mail address: hanson@dfn.com Telephone No. 505-622-7330

(This space for State use)

APPROVED BY Mary W. Wink TITLE OC FIELD REPRESENTATIVE II/STAFF MANAGER DATE 02/09/2004

Conditions of approval, if any:

FEB 17 2004