Form 3160-5 (August 2007)

UNITED STATES OCD-HOBBS

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

FORM APPROVED
OMB No. 1004-0137
Expires: July 31, 2010

5. Lease Serial No. LC 031695A

6. If Indian, Allottee or Tribe Name

N/A

SUBMIT IN TRIPLICATE – Other	7. If Unit of CA/Agreement, Name and/or No.		
1. Type of Well	o W. U.V.		
Oil Well Gas Well Other	8. Well Name and No. Warren Unit # 4		
Name of Operator ConocoPhillips Company	9. API Well No. 30-025-07850		
3a. Address	3b. Phone No. (include area code)		10. Field and Pool or Exploratory Area
P.O. Box 51810 Midland, Tx 79710	423-688-6943		Warren McKee
4. Location of Well (Footage, Sec., T.,R.,M., or Survey Description,	11. Country or Parish, State		
1980 FSL & 660 FWL UL: L of 29-20S-38E		,	Lea County, NM
12. CHECK THE APPROPRIATE BC	OX(ES) TO INDICATE NATURE	OF NOTIC	E, REPORT OR OTHER DATA
TYPE OF SUBMISSION TYPE OF ACT			ОИ
Notice of Intent Acidize	Deepen Deepen	Produ	ction (Start/Resume) Water Shut-Off
Alter Casing	Fracture Treat	Recla	mation Well Integrity
✓ Subsequent Report	New Construction	Recon	nplete
Change Plans	Plug and Abandon	Temp	orarily Abandon
Final Abandonment Notice Convert to Injection	Plug Back	☐ Water	Disposal
13. Describe Proposed or Completed Operation: Clearly state all per the proposal is to deepen directionally or recomplete horizontal Attach the Bond under which the work will be performed or pro	ly, give subsurface locations and r	neasured and	d true vertical depths of all pertinent markers and zones.

following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has

- 1. Remove well head, anchors, flowline, and all other debris from location and install dry hole marker
- 2. Remove caliche and containinated soil from location and access road
- 3. Put in 2'-3' caliche for barrier where needed
- 4. Put in 1'-2' clean topsoil as needed
- 5. Level and contour to surrounding area
- 6. Build an earthen berm at access to prevent vehicular traffic
- 7. Rip and seed all disturbed areas with BLM # 2 seed mix

determined that the site is ready for final inspection.)

Job completed on 5/4/2010

RECEIVED

FEB 08 2011 HOBBSOCD

14. I hereby certify the Donna Williams	hat the foregoin,	g is true and correct. Name (Printed	Title Sr. Regulatory S	Specialist			
Signature	Ju	u)	Date 06/04/2010	ACCEPTED FOR DECO	100		
THIS SPACE FOR FEDERAL OR STATE OFFICE USE							
Approved by		* POTPICT SI	1953/1568/GEN ES/A MANA/S	FEB 4 2011			
Conditions of approva that the applicant hold entitle the applicant to	al, if any, are atta is legal or equita o conduct operat	ached. Approval of this notice does able title to those rights in the subjections thereon.	not warrant or certify rease which would Office	DUD/AU OF LAND MANNOS			
Title 18 U.S.C. Section fictitious or fraudulen	on 1001 and Title at statements or	e 43 U.S.C. Section 1212, make it a representations as to any matter with	crime for any person knowingly and willful nin its jurisdiction.	fully to make to any department or agency of the United States an	ny false		