RU. OF COPICS PECCEVED		Form C - 103
DISTRIBUTION	•	Supersedex Old C+102 and C-103
ANTA FE	NEW MEXICO OIL CONSERVATION COMMISSION	Effective 1-1-65
ILC	· 	
.5.6.5.		5a, Indicate Type of Leave
AND OFFICE		State X   Pec
PELLATOR		5, State OH & Gas Leave No.
		Ì
CONCO	Y NOTICES AND REPORTS ON WELLS	
PARTY OF THE PORT OF TOR OOF	2.0541% 10 . ባኒቲዊ ውዘ 16 ሶርያኮኖኤ ሪዝ የተነፅ ያዳርድ ነው እ DIFFERSMY RESERVOIR»	
Cal appetitute	TO PLANT I POR COLLEGE VALUE OF THE PROPERTY O	7. Unit Agreement Name No. 1
6/1 (A3	Injection Well	No. Caprock Queen Unit
With with	DINER	6. Farm of Louse Name
	nhi an	No. Caprock Queen Unit
Vega Petroleum Corpora Kidiess of Operator	acton	9. Well No.
•	nd morror 70701	Tract 3, Well No. 16
P. O. Box 2383, Midlar	nd, Texas 79701	10. Field and Pool, or Wildert
Lecation of Well	, , , , , , , , , , , , , , , , , , , ,	Canrock Oueen (Lea)
UNIT LETTER P	660 FERT FROM THE South LINE AND 660 FEET	THOM THE THE THE THE THE
	20.0	
THE East LINE, SECTION	N 12-S RANGE 32-E	MANNE MANNE MANNE
	15. Elevetion (Show whether DF, RT, GR, etc.)	12. County
		Lea
Check A	Appropriate Box To Indicate Nature of Notice, Report of	or Other Data
NOTICE OF IN		UENT REPORT OF:
REDRIM REMEDIAL WORK	PLUG AKO ABANDON REMEDIAL WORK	ALTERING CASING
MPGRARILY ABANDON	COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT
<u> </u>	CHANGE PLANS CASING TEST AND CEMENT JOB	
LL CA ALTER CASING	OTHER	
U.H.R.		
Describe Proposed or Completed Ope	erations (Clearly state all pertinent details, and give pertinent dates, inc	cluding estimated date of "starting any propos
work) SEE RULE 1103.		
1. Displaced hole with	th 2500# per 100 bbls. salt base mud.	
2. Set CIBP at 2800'.	<del>-</del>	
Z. Set CIDE at 2000	•	•
3. Set 100' cement pl	lug on top of CIBP.	
3. Set 100' cement p. 4. Cut off and pulled	lug on top of CIBP. d 7" casing at 800'.	
3. Set 100' dement pode. Cut off and pulled 5. Spotted 40 sx. cer	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub.	ub.
3. Set 100' cement pode. Cut off and pulled 5. Spotted 40 sx. cement 6. Spotted 40 sx. cement pode.	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and st	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and st	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cem 6. Spotted 40 sx. cem 7. Spotted 10 sx. cem	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cen 6. Spotted 40 sx. cen 7. Spotted 10 sx. cen 8. Cleaned up location	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub ment plug at surface and erected 4-1/2" regulation for NMOCC inspection.	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cen 6. Spotted 40 sx. cen 7. Spotted 10 sx. cen 8. Cleaned up location	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub. ment plug at surface and erected 4-1/2" regula	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cen 6. Spotted 40 sx. cen 7. Spotted 10 sx. cen 8. Cleaned up location	lug on top of CIBP.  d 7" casing at 800'.  ment plug in-and-out of 7" casing and stub.  ment plug in-and-out of surface casing and stub  ment plug at surface and erected 4-1/2" regulation for NMOCC inspection.	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cen 6. Spotted 40 sx. cen 7. Spotted 10 sx. cen 8. Cleaned up location	lug on top of CIBP. d 7" casing at 800'. ment plug in-and-out of 7" casing and stub. ment plug in-and-out of surface casing and stub ment plug at surface and erected 4-1/2" regulation for NMOCC inspection.	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cen 6. Spotted 40 sx. cen 7. Spotted 10 sx. cen 8. Cleaned up location	lug on top of CIBP.  d 7" casing at 800'.  ment plug in-and-out of 7" casing and stub.  ment plug in-and-out of surface casing and stub  ment plug at surface and erected 4-1/2" regulation for NMOCC inspection.	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cen 6. Spotted 40 sx. cen 7. Spotted 10 sx. cen 8. Cleaned up location	lug on top of CIBP.  d 7" casing at 800'.  ment plug in-and-out of 7" casing and stub.  ment plug in-and-out of surface casing and stub  ment plug at surface and erected 4-1/2" regulation for NMOCC inspection.	
3. Set 100' cement p. 4. Cut off and pulled 5. Spotted 40 sx. cen 6. Spotted 40 sx. cen 7. Spotted 10 sx. cen 8. Cleaned up location	lug on top of CIBP.  d 7" casing at 800'.  ment plug in-and-out of 7" casing and stub.  ment plug in-and-out of surface casing and stub  ment plug at surface and erected 4-1/2" regulation for NMOCC inspection.	