

DISTRIBUTION		
NTA FE		
LE		
S.O.S.		
AND OFFICE		
PERATOR		

N MEXICO OIL CONSERVATION COMMISSION

Supervisors Use
C-102 and C-101
Effective 1-4-85

10. Indicate Type of Lease	
State ☒	Fee ☐
11. State Oil & Gas Lease No.	
OG 1981	

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REPER OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT TO DRILL OR TO REPER OR PLUG BACK TO A DIFFERENT RESERVOIR."

12. Unit Agreement Name	
13. Form or Lease Name	
Flying "M" State	
14. Well No.	
1	
15. Field and Pool, or Village	
Flying "M" (Abo)	
16. County	
Lea	

17. Unit Agreement Name	
18. Form or Lease Name	
Flying "M" State	
19. Well No.	
1	
20. Field and Pool, or Village	
Flying "M" (Abo)	
21. County	
Lea	

15. Elevation (Show whether DF, RT, GR, etc.)	
4374' KB	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

1. POOH with rods & tubing.	2. GIH with RBP & RTTS packer.	3. Set RBP @ 8660'. Spot acid across interval from 8635' - 8620' (existing perfs are 8622' - 24' and 8630' - 34' with 2 SPF). Pick up and set packer at 8600'.	4. GIH with thru tubing gun and perforate interval from 8620' - 8636' with 2 SPF. POOH with gun.	5. Acidize perfs with 2100 gal 20% NEFE HCl acid. Flush to bottom perf.	6. Unseat packer and RBP. Pick up and set RBP @ 8615'. Test to 1500#.	7. Spot acid across interval from 8608' - 8575'. Set packer at 8550'. Perforate interval from 8600' - 8608' with 2 SPF. Acidize perfs with 1600 gal 20% NEFE HCl acid.	8. Swab test to evaluate.
-----------------------------	--------------------------------	--	--	---	---	--	---------------------------

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1123.

1. POOH with rods & tubing.
2. GIH with RBP & RTTS packer.
3. Set RBP @ 8660'. Spot acid across interval from 8635' - 8620' (existing perfs are 8622' - 24' and 8630' - 34' with 2 SPF). Pick up and set packer at 8600'.
4. GIH with thru tubing gun and perforate interval from 8620' - 8636' with 2 SPF. POOH with gun.
5. Acidize perfs with 2100 gal 20% NEFE HCl acid. Flush to bottom perf.
6. Unseat packer and RBP. Pick up and set RBP @ 8615'. Test to 1500#.
7. Spot acid across interval from 8608' - 8575'. Set packer at 8550'. Perforate interval from 8600' - 8608' with 2 SPF. Acidize perfs with 1600 gal 20% NEFE HCl acid.
8. Swab test to evaluate.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed Bobby L. Smith TITLE Petroleum Engineer DATE 11-10-86

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT SUPERVISOR

APPROVED BY _____ TITLE _____ DATE NOV 1 1986