

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
<b>E 8834</b>

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> <b>Oil oil</b>	7. Unit Agreement Name
2. Name of Operator <b>Sunray Oil Company</b>	8. Farm or Lease Name <b>N.M. State "T"</b>
3. Address of Operator <b>P.O. Box 128, Hobbs, New Mexico</b>	9. Well No. <b>2</b>
4. Location of Well UNIT LETTER <b>C</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM <b>West</b> LINE, SECTION <b>1</b> TOWNSHIP <b>10S</b> RANGE <b>33E</b> NMPM.	10. Field and Pool, or Wildcat <b>Lane Penn</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4272 GR</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
DILL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Load hole w/mud, place 25 sx cnt. plug over perfs 4607-4669.
2. Cut off 7" csg @ 4225' & pull.
3. Place 25 sx cnt. plug over 7" csg. stub @ 4225 & 25 sx plug at bottom of 9 5/8" csg. @ 4025'.
4. Place 10 sx @ surface, cut off csg. @ G.L., install Dry hole marker, level location and clear of junk.

13. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <b>C. J. Mc Clellan</b>	TITLE <b>District Engineer</b>	DATE <b>4-8-65</b>
APPROVED BY <b>Leslie A. Clements</b>	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		