

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-10612	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Amerada Hess Corporation	8. Farm or Lease Name State BT"I"
3. Address of Operator 1209 South Main, Lovington, New Mexico	9. Well No. 2
4. Location of Well UNIT LETTER <u>K</u> , <u>1980'</u> FEET FROM THE <u>West</u> LINE AND <u>1980'</u> FEET FROM THE <u>South</u> LINE, SECTION <u>2</u> TOWNSHIP <u>12-S</u> RANGE <u>33-E</u> NMPM.	10. Field and Pool, or Wildcat Bagley-Pennsylvanian
15. Elevation (Show whether DF, RT, GR, etc.) 4252 D.F.	12. County Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUS AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUS AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

## 17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

State BT"I" #2 - Cut 5-1/2" Csg. @ 3195' and spot 35 sack plug through 2-3/8" tubing 3265' to 3165'. Cut 8-5/8" Csg. @ 518' and spot 75 sack plug through 2-3/8" tubing 565' to 465'. Spot 75 sack plug in & out of 13-3/8" Csg. through 2-3/8" tubing 350' to 250'. Spot 20 sack plug in 13-3/8" from 0' to 24'. Install Dry Hole Marker and Cleaned up Location. Work Completed on 1-25-73. Csg. was loaded with Salt-Water Mud.

## 18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>[Signature]</u>	TITLE <u>Area Supt.</u>	DATE <u>3-19-73</u>
SIGNED <u>[Signature]</u>	TITLE <u></u>	DATE <u></u>