

4. RIH W/ REDR 7" OTIS PERMA-LATCH PKR, OTIS OSTSD ON/OFF TOOL, 340 JTS 3-1/2", 9.3#, N-80 & J-55 PC TBG. SET PKR @ 10723' W/ 10000# TENSION. REMOVE BOP. INSTALL WH.
5. MIRU BJ SERVICES PUMP TRK & LINES. TRAP 500# ON CSG. ACDZ OH 10852-11275' W/ 7500 GAL 15% HCL W/ NE SURF & FE AGENT IN 3 STAGES W/ 2000 GAL 10# GEL & 4000# GRS AS FOLLOWS:

STAGE 1: 2500 GAL 15% NEFE HCL. MP 5000#, 3-5 BPM
1000 GAL 10# GEL BRINE W/ 2#/GAL GRS
STAGE 2: 2500 GAL 15% NEFE HCL. MP 5000#
2500 GAL 10# GEL BRINE SPACER
1000 GAL 10# GEL BRINE W/ 2#/GAL GRS ADJUSTED ACCORDINGLY
STAGE 3: 2500 GAL 15% NEFE HCL. MP 5000#

DISPLACE TBG W/ 95 BBLS LSE WTR. RD.
6. IMMEDIATELY BACKFLOW WELL & SWAB OUT SPENT ACID LOAD. RUN STATE NEW MEXICO CSG INTEGRITY TEST. TEST CSG TO 500# FOR 15 MIN & RECORD ON PRESSURE CHART.
7. RETURN WELL TO INJECTION.