

**ATTACHMENT TO FORM C-105
COLLINS & WARE, INC
W.E. MATHERS A #1**

26. Perforation Record

10,938 – 10,966	4 SPF	10/51	Devonian
9385 – 9397	1 SPF (12 shots)	8/68	Penn
8971 – 9324	2 SPF	3/73	Penn
9748 – 9862	2 SPF (80 holes)	7/98	Lower Penn

27. Treatment Record

10,938 – 10,966	AT with 500 gals 15% LST acid.	10/51
10,938 – 10,966	AT with 2000 gals 15% LST acid.	10/51
10,938 – 10,966	AT with 5000 gals 28% NE acid.	7/67
9430	Set "WASP" BP at 9430'.	8/68
9385 – 9397	AT with 4250 gals acid.	
9318 – 9324	AT with 250 gals MBA and 1500 gals 15% NE acid.	3/73
9202 – 9218	AT with 250 gals MBA and 1500 gals 15% NE acid.	3/73
9940	Push BP at 9430 down to 9940'.	7/98
9927	Set 5 ½" CIBP at 9927' and dump 15' of cement on top making PBTD at 9912'.	
9748 – 9862	AT with 4000 gals of 15% Fer-chek acid with 160 ball sealers.	7/98