

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

HOBBS OFFICE O. C. C.
NEW MEXICO OIL CONSERVATION COMMISSION

Mar 10 11 17 AM '66

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name	
9. Well No.	
10. Field and Pool, or Wildcat	
12. County	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	2. Name of Operator	3. Address of Operator	4. Location of Well
	Trice Production Company	Drawer 2232 - Longview, Texas 75601	UNIT LETTER D , 660 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 10 TOWNSHIP 9S RANGE 34E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)			16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
4262 DF			NOTICE OF INTENTION TO:
			SUBSEQUENT REPORT OF:
			PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/>
			TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
			PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/>
			OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.) SEE RULE 1103.

- Set plug of 20 sacks from 6500' to 6340' inside 5-1/2".
- Shot pipe at free point 4670'; Pulled 5-1/2".
- Spot 25 sacks cement plug from 4670' to 4590'.
- Spot 25 sacks cement plug from 4130' to 4050'.
- Set 10 sacks cement plug at 0'.
- Left in hole 5-1/2' from 9638 to 4670' with tubing anchor at 6500'.
Also, 8-5/8' set at 4090' cemented to surface 13-3/8" casing 434'.

Completed February 19, 1966

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED	TITLE	DATE
<i>John W. Runyan</i>	Production Foreman	March 8, 1966
APPROVED BY	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		

[illegible]

SECRET