

¹ *Journal of the American Medical Association*, 273, 1994, 2321-2324.

FROM-	TO-	TOTAL FEET	FORMATION
9060	9088	28	Line & Chert
9088	9753	665	Line & shale
9753	9789	36	Line & shale
9789	9824	35	Gray line, shaley & fine
9824	9857	33	Gray to tan shaley line
9857	9903	46	Penn. line
9903	9958	55	Shale & Line
9958	9981	26	Line
9981	10014	30	Shale & Line
10014	10235	221	Line & shale
	10235	Total Depth	Set 7" casing on bottom @ 10235'. Cement below collar @ 9833' w/175 sacks and through collar w/1675 Sacks.
TESTS AND NUMBERS OF PERFORATIONS:			
Perf. 7" Csg. 9870-72 w/4 SPF (Jet). Run 2" tubing with Guiberson Hook Wall packer to 9810'. Swab 15 bbls. Salt Water with slight staining oil 3 hours.			
Perf. 7" Csg. 9866-70 w/4 SPF (Jet). Run 2" tubing with Guiberson Hook Wall packer at 9854'. Swab 2 bbls. drilling mud cut with salt water no oil or gas showing 20 hours. With caving tubing bailer rec. 8 gal. mud, no oil, gas or water 4 hours. Swab 10 gals. drilling mud cut with salt water, no gas or oil 13 hours.			
Well temporary abandoned to await further development in area. Temporarily Abandoned June 20, 1950.			