

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>00 2275</b>
7. Unit Agreement Name
8. Farm or Lease Name <b>N.M. State "AI"</b>
9. Well No. <b>1</b>
10. Field and Pool, or Wildcat <b>Undesignated</b>
12. County <b>Lea</b>

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry Hole</b>
2. Name of Operator <b>Sunray Oil Company</b>
3. Address of Operator <b>P.O. Box 128, Hobbs, New Mexico</b>
4. Location of Well UNIT LETTER <b>M</b> , <b>330</b> FEET FROM THE <b>West</b> LINE AND <b>330</b> FEET FROM THE <b>South</b> LINE, SECTION <b>4</b> TOWNSHIP <b>9</b> RANGE <b>32</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>1110' DF</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. P&A as follows:

a. Cut off  $4\frac{1}{2}$ " csg @ 2450' & pulled.

b. Load hole w/mud.

c. Lay cnt plug as follows: 25 sx @ 3430-3000'

25 sx @ 2471-2371'

25 sx @ 1700-1650'

25 sx @ 365-29

10 sx in top of 8 5/8" csg.

2. Install dry hole marker, level & clear location of all junk. P&A 1-12-65.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <b>B.F. Brawley</b>	TITLE <b>District Engineer</b>	DATE <b>1-15-65</b>
APPROVED BY <b>Testis V. Clements</b>	TITLE	DATE <b>NOV 10 1965</b>
CONDITIONS OF APPROVAL, IF ANY:		