

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <u>Petro Lewis Corporation Midland</u> <i>Neadee Properties, Ltd.</i>	8. Form or Lease Name <u>Thompson</u>
3. Address of Operator <u>% Hobbs Pipe & Supply Post Office Box 2010 Hobbs, New Mexico 88240</u>	9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>724</u> FEET FROM THE <u>West</u> LINE, SECTION <u>23</u> TOWNSHIP <u>11</u> RANGE <u>36</u> N.M.P.M.	10. Field and Pool, or Wildcat <u>North Bagley</u>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <u>Lea</u>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Hole was loaded with mud laden fluids
- Set 100' Plug across perforations
- Set 100' Plug at stub of 5 1/2" casing @6,900'
- Set 100' Plug at 4,700'
- Set 100' Plug in and out of 8 5/8" casing shoe
- Set 100' Plug at base of surface casing
- Set a 10sx Plug @ surface and erect a 4" Regulation marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Benny Cartmel</u>	TITLE <u>Agent</u>	DATE <u>January 20, 1976</u>
APPROVED BY <u>John W. Remyan</u>	TITLE <u>Geologist</u>	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		