

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. OG-5085

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator BTA Oil Producers	8. Farm or Lease Name Somico 682 Ltd.
3. Address of Operator 104 South Pecos, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>C</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>20</u> TOWNSHIP <u>10-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat Vada-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4230 GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
-------------------------	-----------------------

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JQB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed Plugging Procedure:

Set CIBP @ 9850 w/2 sx cmt on top
Cut & pull 4½" csg
25 sx @ 4½" stub
25 sx @ 5500 (Glorietta)
25 sx @ 3820 (8-5/8" shoe)
Cut & pull 8-5/8" csg
25 sx @ 8-5/8" stub
25 sx @ 367 (12-3/4" shoe)
10 sx @ surface
Install dry hole marker per NMOCC regulations

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>L. R. Boyce</u>	TITLE <u>Production Clerk</u>	DATE <u>9/3/71</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>SECRETARY</u>	DATE <u>SEP 7 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

SEP 17 1971

OIL CONSERVATION COMM.
HOUSTON, TEX.