

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
----------------------------	--

5. State Oil & Gas Lease No.
K-117

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name None
2. Name of Operator BLACKROCK OIL COMPANY	8. Farm or Lease Name State K
3. Address of Operator 1701 Cotton Flat Road, Midland, Tx 79701	9. Well No. 1
4. Location of Well UNIT LETTER J , 1980 FEET FROM THE East LINE AND 1980 FEET FROM THE South LINE, SECTION 10 TOWNSHIP 10-S RANGE 32-E NMPM.	10. Field and Pool, or Wildcat Mescalero (San Andres)
15. Elevation (Show whether DF, RT, GR, etc.) 4325' G.L.	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1.) Set cast iron bridge plug @ 4015' in 4-1/2" casing, dump 4 sx cement on top.
- 2.) Cut 4-1/2" casing at 1079', spot 35 sx cement plug at 1079'.
- 3.) Spot 25 sx @ 650'.
- 4.) Spot 35 sx cement plug @ 450'.
- 5.) Pull casing, spot 10 sx cement plug in top of 8-5/8" casing.
- 6.) Install marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *O. D. Butler* **O. D. Butler** TITLE President DATE March 24, 1975

APPROVED BY *Eddie W. Scan* TITLE OIL & GAS INSPECTOR DATE MAY 17 1983
CONDITIONS OF APPROVAL, IF ANY: