

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-6101	
7. Unit Agreement Name	
8. Farm or Lease Name	
State 11711	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Vada Penn	
12. County	
Log	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	2. Name of Operator
3. Address of Operator	4. Location of Well
503 27th Street Lubbock, Texas 79407	UNIT LETTER K 1000 FEET FROM THE South LINE AND 1000 FEET FROM THE West LINE, SECTION 10 TOWNSHIP 10-RANGE 34-NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)	16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Set 50 sack cement plug at 6800'.
Set 50 sack cement plug at 5100' to 5000'.
Shot 4 1/2" Casing at 3632'.
Set 50 sack cement plug at 3582' to 3682'.
Set 75 sack cement plug at 273' to 1073'.
Set 75 sack cement plug at 403' to 503' in and out of 8 5/8" casing.
Set 10 sack cement plug at surface and installed dry hole marker.
(8 5/8" Casing Shot off at 1023' and recovered)
Well was circulated with, and all plugs set with fresh water gelled mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Gene Melford TITLE Agent DATE 7/31/77

APPROVED BY John W. Remyer TITLE Geologist DATE 7/31/77

CONDITIONS OF APPROVAL, IF ANY: