

11-9-87

Ran swab to check fluid level. Found top of fluid 200' from surface. Lowered rotary shoe to check for fill. Hole was clean to top of swedge. Picked up off top of fish and started swabbing well down at 9:00 A.M. Swabbed to 4500'. Shut down for night at 6:00 P.M.

11-10-87

Swabbed to 5500' in 2½ hours. Laid down swab and pulled out of hole with rotary shoe. Tripped in hole with screw in sub jars, Accel sub, 4-3½" OD DCs and 2-3/8" tubing. Screwed into top of jars. Started jarring on fish at 2:00 P.M. Got fish loose at 2:45 P.M. and started pulling out of hole with slight drag. Completed pulling out of hole. Rec. W.L. tools. Shut down for night at 5:30 P.M.

11-11-87

Tripped in hole with 1 joint tail pipe, 4-5/8" OD string mill, BS, jars, 4-3½" OD DCs and 2-3/8" tubing. Scraped 5½" casing to top of collapse at 6545' depth. Pulled out of hole with string mill. Tripped in hole with 4-5/8" OD string swedge on work string. Got to 6200'. Shut down for night at 4:00 P.M. Will start driving swedge into collapsed area in A.M.

11-12-87

Pumped 75 barrels hot fresh water down casing to clean paraffin from casing wall. Worked swedge to top of collapse at 6545' depth. Started swedging at 2:00 P.M. No progress in 3 hours. Pulled out of hole with 4-5/8" swedge. Tripped in hole with 4½" OD swedge. Tagged up at top of collapsed spot at 3:30 P.M. and started driving swedge through tight spot. Made 1' progress in 1½ hours. Pulled 8 stands to get above all tight casing and shut down for night at 5:30 P.M.

11-13-87

Drove 4½" OD swedge through tight interval from 6545' to 6548' in 1½ hours working. Continued working swedge through tight spot for additional 1½ hours. Required bumping through and jarring out at end of working. Pulled out of hole with swedge. Picked up 4½" bit and tripped in hole on 314 joints 2-3/8" tubing. Tagged up with 7' in on 315th joint. Present depth 9797.21' zeroed 3' AGL. Indicates 9' additional fill. Did not feel anything while going through collapsed area from 6545' to 6548'. Started laying down 2-3/8" tubing on float at 2:30 P.M. Laid down 112 joints to get 4½" bit above 6545' depth. Shut down for night at 4:00 P.M.

11-14-87

Shut down for weekend.

11-15-87

Shut down for weekend.

11-16-87

Completed laying down tubing on float. Laid down drill collars. Closed in well. Rigged down PBCP Services, Inc. at 1:00 P.M.