

Page 2

We propose the following:

- (1) Clean out to original PBD of 9855'.
- (2) Restore well to production.
- (3) Plug and abandon in accordance with Sundry Notice dated 11-25-86 if above efforts are unsuccessful.