

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRI
ORIGINAL INSTRUCTIONS
ON REVERSE SIDE

Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

NM 0127905

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

M & G Oil, Inc.

3. ADDRESS OF OPERATOR

P.O. Box 766 Tatum, New Mexico 88267

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FNL and 660' FEL
Sec. 12, T-9-S, R-35-E
Lea County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4145 GR

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Morton Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Vada Penn

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 12, T-9-S, R-35-E

12. COUNTY OR PARISH 13. STATE

Lea

N.M.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

REPAIRING WELL

☐
☐
☐

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set cast iron bridge plug at 9739' (100' above 5 1/2" casing perforations). Cap with 35' of cement and load hole with salt gel mud.
2. Spot 150' cement plug across top of Wolfcamp at 8935'. Tag top of cement.
3. Burst 5 1/2" casing at 6975' at top of Tubb and spot 150' cement straddling this point. Tag top of cement.
4. Burst 5 1/2" casing at the 8 5/8" casing shoe at 4050' depth and spot 150' straddling this point. Tag top of cement.
5. Burst 5 1/2" casing at top of salt section at 2285' and spot 150' cement plug straddling this point.
6. Salvage 5 1/2" casing at a point between the 13 3/8" casing shoe at 372' and top of the salt section at 2285'.
7. Spot 150' cement plug straddling top of 5 1/2" casing. Tag top of cement.
8. Burst 8 5/8" casing at the 13 3/8" casing shoe at 372' and spot 150' cement plug straddling this point. Tag top of cement.
9. Spot 50' cement plug at surface and erect dry hole marker.

18. I hereby certify that the foregoing is true and correct

SIGNED

Wm. Groesbeck

TITLE

Vice President

DATE

9-5-86

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

9-9-86

CONDITIONS OF APPROVAL, IF ANY: