

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
(Other instructions on the
reverse side)Form approved.
Budget Bureau No. 42 R1424.
5. LEASE DESIGNATION AND SERIAL NO.

N.M. 0348788-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

APR 30 1980

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

The Maurice L. Brown Company

3. ADDRESS OF OPERATOR

Suite 200/Sutton Place Bldg. Wichita, Kansas 67202

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

UL "J". 1980' from South line and 1980' from East line.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4141' KB

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Feather 688 Ltd.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Vada Penn

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 1 T-9-S, R-35-E

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Moved in and rigged up PBCP Services, Inc.
2. Pull tubing.
3. Run cement retainer on tubing and set at 6455' (50' above casing separation at 6505' as determined by McCullough caliper survey on 2-15-80).
4. Squeeze cement below retainer with 100 sacks of Class "H" cement.
5. Salvage 5 1/2" casing from free point anticipated to be at 5000' depth.
6. Spot 100' cement plug through tubing from 50' below top of 5 1/2" casing stub. Tag top of cement.
7. Spot 100' cement plug through tubing at 4134' depth (50' below 8 5/8" casing shoe at 4034'). Tag top of cement.
8. Spot 100' cement plug through tubing at 2100' across top of salt section.
9. Salvage 8 5/8" casing at free point anticipated to be at 1000' depth.
10. Spot 100' cement plug through tubing from 50' below top of 8 5/8" casing stub. Tag top of cement.
11. Spot 100' cement plug through tubing at 425' depth (50' below 12 3/4" casing shoe at 375'). Tag top of cement.
12. Spot 10' cement plug inside 12 3/4" casing at surface.
13. Erect dry hole marker.
14. Rigged down PBCP Services, Inc.
15. Clean and level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

Wm. Brosbeck

TITLE

District Engineer

DATE

4-29-80

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

MAY 1980

WLB

For [unclear]