

Wolf Federal cont.

9. Spot 50' cement plug at surface and erect dry hole marker.
10. Fill mud pit and cellar and clean and level location.