

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>

5. State Oil & Gas Lease No.
OG-5332

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - M" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator BTA Oil Producers	8. Farm or Lease Name Cap 692 Ltd.
3. Address of Operator 104 S. Pecos Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER "E" 1980 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 9-S RANGE 35-E NMPM.	10. Field and Pool, or Wildcat Vada-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4157' GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>

SUBSEQUENT REPORT OF:	
REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed Procedure:

Call NMOCC - Hobbs - 505/393/6161 - 24 hrs. advance
Hole to be filled w/mud laden fluid.

Pull 2-7/8" tbg & anchor catcher
Set CIBP @ 9700' w/3 sx cmt. on top.
Cut & pull 5-1/2" csg. T/C 8100'.
Set 50 sx @ 5-1/2" stub.
Set 50 sx @ 5465' (Glorietta).
Set 50 sx @ 4060'.

Cut & pull 8-5/8" csg.
Set 50 sx on 8-5/8" stub.
Set 50 sx @ 382'.
Set 10 sx @ surface.

~~Install dry hole marker.~~

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Jones TITLE Production Clerk DATE 9/8/72

APPROVED BY Joe D. Ramey TITLE Dist. 1, Supv. DATE SEP 11 1972
CONDITIONS OF APPROVAL, IF ANY: