Mathers #2 (cont.) Page 2

- 2-27 Finish/Hw/ 4-9/16 shoe & washover Ass'y/tag & clean fill 9552-9555 in 6 hrs/PU to 8600.
- 3-1 Lower shoe tag & clean out fill 9553-9555/Mill on RBP 9555-56<sup>1</sup>/<sub>2</sub> 1<sup>1</sup>/<sub>2</sub>'/POH w/washover ass'y, changed shoes/RIH w/washover ass'y to 8626.
- 3-2 Lower shoe tag & clean out fill  $9555-56\frac{1}{2}$  / Milled new hole  $9556\frac{1}{2}-58$  in  $4\frac{1}{2}$  hrs, no hole made last hr, regain partial returns last 3 hrs/POH w/washover ass'y found shoe worn smooth.
- 3-3 RIH w/shoe & washover ass'y/tag & mill 9558-59 fell free lower & tag 9594/ Mill 9594-95 rec metal & ball sealers/POH w/washover assy rec 21' 2-3/8 tbg change over sub and ret tool in washpipe/ prep rerun shoe & washover ass'y this am.
- 3-4 12 hrsSITP 150# / RIH w/shoe (#6), 2 jts wash pipe, jars 6-3½DC on 2-7/8tbg/ tag & mill 9595-97 in 5½ hrs w/no circ No hole made last 2 hrs/POH to 8100.
- 3-5 12 hrs SITP 150/POH w/DC, jars and washpipe w/shoe/TIH w/4"X2-5/8 short catch o'shot, Bumper sub, jars 6-DC and accelerator to 9597, unable to latch fish, no circ, w/110 bbls, POH to 4947.
- 3-8 Finish POH w/overshot & fishing Ass'y Rec ret. head & equal. Sleeve/RIH w/4-9/16 X 3-5/8 shoe 2 jts washpipe jars 6-3½ DC on 3-7/8 tbg / tag & washover 9596-98½ in 4½ hrs w/no circ to surf No progress last hr/POH to 8184.
- 3-9 Finish POH change washover shoe/RIH w/washover assy/ tag & mill  $9598\frac{1}{2}$ -99 in  $5\frac{1}{2}$  hrs w/no circ No hole made last hr/POH to 8185.
- 3-10 Cont POH w/washover Assy found shoe in new cond/RIH w/4-7/16 over shot w/2-9/16 grapple jars Bumper sub  $6-3\frac{1}{2}$  DCs on 2-7/8 tbg/tag & attemp latch RBP/POH rec top 3" of inner mandrell.
- 3-11 RIH w/4-7/16 X 2-9/16 overshot bumper sub jars 6-3½ DCs on 2-7/8 tbg/tag & attemp latch RBP at 9599/ POH w/ no rec Grapple marked w/2-7/8 OD imprint/ RIH 4-7/16 X 2-7/8 over shot & fishing ass'y/tag & attempt latch RBP/PCH to 8185.
- 3-12 POH w/overshot & fishing Assy w/no rec/ RIH w/5½ RDG to 8996 unable to go lower/POH change Pkrs/RIH w/5½ RDB to 9088.
- 3-15 60 hr SITP 180#/lower & set RDB @ 9581.
- 3-16 POH w/Pkr & tbg / RIH w/2-7/8 pump setup TS 9548 SN 9515 TAC 9423.
- 3-17 RIH w/ $1\frac{1}{2}$  pump & Reds.
- 3-18 Balance pumping unit, autic start up today.
- 3-29 24 hrs, P, 25 BO, 110 BLW, 169 MCF, GOR 6760/1, 11 X 88 X 1<sup>1</sup>/<sub>2</sub>.