

OIL CONSERVATION DIVISION

P. O. BOX 2008

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-79

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FIELD	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State ☐	For ☒
5. State Oil & Gas Lease No.	
NM-1107	

SUNDARY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR APPLICATION TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
(SEE APPLICATION FOR PERMIT - FORM C-101) FOR SUCH PROPOSALS.)

1. CIL ☒ CAS ☐ OTHER ☐		7. Unit Agreement Name	
2. Name of Operator		8. Firm or Lease Name	
THE SUPERIOR OIL COMPANY		HAMM COM	
3. Address of Operator		9. Well No.	
P. O. BOX 4500 THE WOODLANDS, TEXAS 77380		1	
4. Location of Well		10. Field and Pool, or Willcut	
UNIT LETTER A 660' FEET FROM THE North LINE AND 510' FEET FROM		VADA (Penn)	
THE East LINE, SECTION 13 TOWNSHIP 9S RANGE 34E			
15. Elevation (Show whether DF, RT, GR, etc.)		12. County	
KB 4207', DF 4205', GL 4195'		Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☒	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU pulling unit. POH rods and pump. NU BOP and kill well.
2. POH w/2 7/8" and 2 3/8" tubing. RIH w/tubing and 17# RTTS and tubing tester. Set RTTS @ 9750'. PT tubing and casing.
3. Spot 1000 gals 15% HCl acid w/corrosion inhibitor and surfactant to perfs w/formation water @ 2-3 BPM.
4. Swab. Set DR plug in Model D pkr @ 9785'. Reset RTTS @ 9580' and test plug to 2000 psi.
5. Add perfs 9759'-9770' and 9656'-9668' w/2 jspf to old perfs (9809'-9825'). Swab test well.
6. Acidize perfs w/2000 gals 15% HCl w/5 gpt HAI-75 and 3 gpt 14N w/46 lit balls @ 3 BPM. Displace w/formation water.
7. RIH w/overshot and retrieve DR plug. POH.
8. RIH w/production string, dh pump and rods.
9. Place well on production and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED L.H. BOHOT L.H. BOHOT TITLE PRODUCTION ENGINEERING SUPERVISOR DATE 12-1-81APPROVED BY Orig. Signed by Les Clements TITLE Oil & Gas Insp. DATE 12-1-81

CONDITIONS OF APPROVAL, IF ANY:

CC: OCD (6), RG