

5. If additional capacity needed, retrieve BP & set approx. 9100' and thru thg perf 9034-40' & 8966-72' w/1-9/16" cased gun loaded 1 SPF & zero phase. Use "Kickover" magnet on gun. Set RTTS tool approx. 8925' & acidize w/2500 gals 20% NE acid. Inject one ball sealer per 175 gals acid. Swb back load wtr & test. Retrieve BP & TOH.
6. TIH w/Kobe csg pump & Mod. "R" SG pkr. Set pump @ approx. 8900'. Return well to production.