

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

ICATE
(Other instructions on re-
verse side)

Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(IP NO. 00) This form for proposals to drill or to deepen or plug back to a different reservoir
Use "APPLICATION FOR PERMIT" for such proposals.)

HOBBS, NEW MEXICO 80240

5. LEASE DESIGNATION AND SERIAL

0202771A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

SW-639

8. FARM OR LEASE NAME

Vada Pruitt

9. WELL NO.

1

10. FIELD AND POOL OR WILDCAT

Vada (Penn.)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Section 1, T9S-R34E

12. COUNTY OR PARISH 13. STATE

Lea

New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

PYRO ENERGY CORP.

3. ADDRESS OF OPERATOR

(214) 637-1999

6303 Harry Hines Boulevard, Suite #206, Dallas, TX 75235

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below)

At surface

1980 FSL and 1980 FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, RT, CR, etc.)

GL Elev.: 4221', KB Elev.: 4230'

16

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

PULL OR ALTER CASING ☒

FRACTURE TREAT ☐

MULTIPLE COMPLETION ☒

SHOOT OR ACIDIZE ☐

ABANDON ☒

REPAIR WELL ☐

CHANGE PLANS ☐

(Other) ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT ☒

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

PLUGGING PROGRAM INTENT FOR VADA PRUITT #1

Surface casing: 8 5/8", set at 3994'. Production casing: 5 1/2", set at 9765'. PBD= 9754'
Top of cement: estimated at 6900'. Perforations: 9717-27'.

1) Move in and rig up.

2) Rig up cementers, run in hole with tubing and set plugs from 7754'-9600'. Pull out
of hole with tubing. *Tag this plug.*

3) Run in hole with casing cutter to ±6900' and cut casing. Pull out of hole with casing.

4) Run in hole with tubing and set plugs from 7000' to 6800'. *Tag plug.*

5) Pick up and set cement plug from 4100' to 3850'. *Tag plug*

6) Pull out of hole and set 10 sackplug at surface.

7) Cut off wellhead, erect dry hole marker and clean up location.

* *additional plugs: 100' cement, 2200'-2100' in 8 5/8" casing
100' cement, 462-362' in 8 5/8" casing*

*as discussed
with
Craig Ledbetter
Rita W. Chatter*

18. I hereby certify that the foregoing is true and correct

SIGNED

Craig Ledbetter
Craig Ledbetter

TITLE Western District Engineer

DATE September 23, 1985

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

11-14-85

***See Instructions on Reverse Side**