

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.
None

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
Anderson Oil & Gas Company, Inc.

3. Address of Operator
250 Mid-America Building, Midland, Texas 79701

4. Location of Well
UNIT LETTER **M** **510** FEET FROM THE **West** LINE AND **660** FEET FROM
THE **South** LINE, SECTION **26** TOWNSHIP **11-S** RANGE **33-E** N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)
4236 GL

7. Unit Agreement Name
None

8. Farm or Lease Name
Midwest

9. Well No.
1

10. Field and Pool, or Wildcat
North Bagley Penn

12. County
Lee

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☒

OTHER ☐

PLUG AND ABANDON ☒

CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING TEST AND CEMENT JOBS ☐

OTHER ☐

ALTERING CASING ☐

PLUG AND ABANDONMENT ☐

OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set 5-1/2" cast iron BP @ 8650' on wire line and cap with 35' cement.
2. Run free point and cut off 5 1/2" casing as indicated - estimate 6500'
3. Spot 100' cement plug in & cut off 5 1/2" casing stub at 6500'.
4. Spot 100' cement plug @ the top of the Glorietta formation @ 5140'.
5. Spot 100' cement plug in and out of the intermediate casing shoe @ 3794'.
6. Run free point and cut 8 5/8" casing as indicated.
7. If salt section is exposed (2360' to 1810') set a 100' cement plug at the bottom and/or at the top of the salt section.
8. If free point is above 1812' set a 100' cement plug in and out of the 8 5/8" casing stub.
9. Set a 100' plug in the shoe of the surface casing @ 433'.
10. Set a 10 ex plug at the surface and cap with a marker showing operator and location.

- * Notify Conservation Commission 24 hrs prior to P & A.
- * Spot 9.5# mud between all plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED William E. Ramey TITLE Engineer DATE 2-15-73

Orig. Signed by
Joe D. Ramey
Dist. 1, Subv.

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: