

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Supersedes Old
C-103 and C-104
Effective 4-1-69

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
1-34	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Southland Royalty Company		8. Farm or Lease Name Sun-State
3. Address of Operator 1100 Wall Towers West Midland, Texas 79701		9. Well No. 1
4. Location of Well UNIT LETTER F 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 23 TOWNSHIP 11-S RANGE 34-E N.M.P.M.		10. Field and Pool, or Wildcat Four Lakes Atoka (N.)
15. Elevation (Show whether DF, RT, CR, etc.) 4144 GR		11. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Load hole. Release tubing from permanent packer.
2. Set plug in packer @ 11,600'. Cap with 35' cement.
3. Displace hole with 10.0# mud.
4. Cut 5 1/2" at 7800' (T/cmt. @ 7900' by T.S.)
5. Spot 100' plug across casing stub.
6. Spot 100' plug across 8 5/8" casing shoe @ 4220'. Tag Plug.
7. Cut 8 5/8" casing. (Estimated top of cement calculated @ 100% fillup 3220').
8. Spot 100' plug across 8 5/8" casing stub.
9. Spot 100' plug @ base of salt 2665'.
10. Spot 100' plug @ top of salt 2105'. Tag plug.
11. Spot 100' plug across 12 3/4" casing shoe @ 350'.
12. Spot 20' plug @ surface.
13. Clean location, install surface marker.

THE COMPLETION MUST BE NOTIFIED 24
HOURS BEFORE THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

100' PLUG AT TOP OF GLORIETA (EXPANDED 5450-5550)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. Harney Can TITLE District Engineer DATE 8-14-79

APPROVED BY [Signature] TITLE SUPERVISOR DISTRICT 1 DATE AUG 17 1979
CONDITIONS OF APPROVAL, IF ANY: