

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator MGF Oil Corporation	8. Farm or Lease Name Thompson 26
3. Address of Operator Box 360, Midland, Texas 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>26</u> TOWNSHIP <u>10-S</u> RANGE <u>36-E</u> NMPM.	10. Field and Pool, or Wildcat East Crossroads San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 3978 GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set 35 Sx. plug f/4900' to 4550'. WOC.
2. Tag plug at 4550'.
3. Set 20 sx. plug f/1000' to 880'.
4. Cut off wellhead. Set 10 sx. plug f/30' to surface.
5. Weld on plate and deadmen. (Operation completed on 12/10/80).

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Ronald M. Culliford</u>	TITLE <u>Engineer</u>	DATE <u>8-4-83</u>
OIL & GAS INSPECTOR		
APPROVED BY <u>William C. Mankel</u>	TITLE <u></u>	DATE <u>FEB 14 1984</u>
CONDITIONS OF APPROVAL, IF ANY:		