

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. V-0083
7. Unit Agreement Name
8. Farm or Lease Name State E.M.
9. Well No. 1
10. Field and Pool, or Wildcat Vada Penn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
Name of Operator ELK OIL COMPANY
Address of Operator P. O. BOX 310, ROSWELL, NEW MEXICO 88201
Location of Well UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 11 TOWNSHIP 10S RANGE 33E N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 4230.5 Grd

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:



REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

On November 30, 1981 plugged well as follows:

1. Set 5½" CIBP @ 5450' w/35' of cement on top of plug.
2. Cut off and pulled 5399' of 5½" casing
3. Set 50 sx plug in and out of 5½" casing stub @ 5400'.
4. Set 65 sx plug @ 8 5/8" shoe.
5. Set 35 sx plug @ 2400' across salt section.
6. Cut off head, set 10 sx plug @ surface w/standard 4' x 4' dry hole marker. Clean and level location.
7. Location ready for inspection.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE President	DATE 2/7/83
APPROVED BY 	TITLE OIL & GAS INSPECTOR DISTRICT SUPERVISOR	DATE
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED
FEB 8 1983
G.C.D.
HOBBS OFFICE