Submit 3 Copies To Appropriate District Form C-103 State of New Mexico Office Revised March 25, 1999 Energy, Minerals and Natural Resources District 1 WELL API NO. 1625 N. French Dr., Hobbs, NM 87240 30-025-27582 District II OIL CONSERVATION DIVISION 811 South First, Artesia, NM 87210 5. Indicate Type of Lease 2040 South Pacheco District III STATE FEE \square 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 6. State Oil & Gas Lease No. **District IV** 2040 South Pacheco, Santa Fe, NM 87505 V-70 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name: (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A State 6 DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Gas Well Other Oil Well X 8. Well No. 2. Name of Operator Novy Oil & Gas, Inc. 9. Pool name or Wildcat 3. Address of Operator 125 N. Market St., Suite 1230, Wichita, KS 67202 Vada Penn 4. Well Location Unit Letter G: 2080 feet from the North line and 1980 feet from the East line County Township 10S Range 34E NMPM Lea Section 6 10. Elevation (Show whether DR, RKB, RT, GR, etc.) 4260 Gr. = 4275 RKB 11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data SUBSEQUENT REPORT OF: NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL WORK ALTERING CASING COMMENCE DRILLING OPNS. **PLUG AND** TEMPORARILY ABANDON CHANGE PLANS **ABANDONMENT** CASING TEST AND □ MULTIPLE
PULL OR ALTER CASING CEMENT JOB COMPLETION OTHER: OTHER: 12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. MIRU TWS Well Service. POOH w/rods & tubing. 1-21-00 MIRU Computer Log Wireline - TIH w/CIBP. Set BP @9785'. POOH. RDMO Computer 1-24-00 Log. TIH w/tbg. Set anchor @ 9779'. TIH w/rods & POP to test Abo perfs. 1-25 to Well made 0 bbl. oil - no fluid entry from Abo. 2-1-00 MIRU TWS Well Service. POOH w/rods & tbg. RU sand line drill & start 2-3-00 drilling up BP. Drill up BP & push to bottom - 9885'. TIH w/tbg. & set anchor @ 9880'. Run 2-4-00 pump & rods & POP. RDMO TWS Well Service. 2-5-00 I hereby certify that the information above is true and complete to the best of my knowledge and belief. DATE 1-6-2000 TITLE President **SIGNATURE** Telephone No. (316) 265-4651 Type or print name Frank E. Novy (This space for State use) DATE APPPROVED BY TITLE

Conditions of approval, if any: