

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Mission Exploration, Inc.		8. Farm or Lease Name Mission "14" State
3. Address of Operator PO Box 2188 Hobbs, New Mexico 88240		9. Well No. 1
4. Location of Well UNIT LETTER <u>I</u> , <u>554</u> FEET FROM THE <u>East</u> LINE AND <u>1986</u> FEET FROM THE <u>South</u> LINE, SECTION <u>14</u> TOWNSHIP <u>10S</u> RANGE <u>33E</u> NMPM.		10. Field and Pool, or Wildcat Inbe Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4204'		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set 50 sx plug from 9713-9460'
- Displaced hole with salt gel mud.
- Set 25 sx plug @ 7550'
- Set 25 sx plug @ 4250'
- Set 25 sx plug across 5 1/2" csg stub in 8 5/8" csg @ 3520'
- Set 25 sx plug in 8 5/8" csg @ 1950'
- Set 10 sx plug @ surface.
- Install dry hole marker
- Cleaned location

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Det Juvico TITLE NRE, Agent for Mission Explor. DATE 8-17-87
APPROVED BY J. J. Juvico TITLE OIL & GAS INSPECTOR DATE NOV 25 1987
CONDITIONS OF APPROVAL, IF ANY: