

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input checked="" type="checkbox"/> WELL GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Mission Exploration Inc.		8. Farm or Lease Name Mission "14" State
3. Address of Operator P. O. Box 2188 Hobbs, NM 88240		9. Well No. 1
4. Location of Well UNIT LETTER I 554 FEET FROM THE East LINE AND 1986 FEET FROM THE South LINE, SECTION 14 TOWNSHIP 10S RANGE 33E NMPM.		10. Field and Pool, or Wildcat Inbe Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4204'		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 9500'. Cap with 35' of cement.
2. Displace hole with salt gel mud.
3. Set 100' cement plug from 7700 - 7600'.
4. Pull 5000' of 5-1/2" casing.
5. Set 100' cement plug across 5-1/2" casing stub, 50' in and 50' out.
6. Set 100' plug across 8-5/8 casing shoe at 4197' (4147-4247').
7. Set 100' plug 1850 - 1950'.
8. Set 10 sx plug at surface.
9. Set dry hole marker. Clean location. Prepare for OCD inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE NRE, Agent for Mission Exp. DATE July 6, 1987

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JUL 8 1987

CONDITIONS OF APPROVAL, IF ANY: