- 01-20 SITP 0, SICP vac. MIRU Rotary WL trk, PU 1-7/16" CCL w/collar shot bar & TIH on WL. Tag up @ 5066' would not go thru. POOH. PU 1-1/2" spud bars & TIH on WL worked thru 5066' & several other spots dwn to 11,192' tight spots are changing. Start POOH w/spud bars hit tight spot @ 7364' got above, but can't get past. POOH, PU 1-5/8" chisel w/spud bars & TIH on WL. Cannot spud past 7364' POOH. PU collar shot bar w/CCL & TIH on WL tag up @ 7364' PU to collar @ 7359' & shoot POOH. Worked tbg would not come free. PU 1-7/16" free point tool & TIH on WL 5000' 100% free, 6000' 100% free, tag @ 6825' tool stopped working scale in slots. PU spud bars w/chisel & TIH on WL worked to 7364' POOH. PU collar shot bar loaded w/1500 grams & TIH on WL. Pull 100,000 into tbg & shoot collar @ 6503' POOH. Worked tbg did not come free. TIH w/shot bar again & shot collar @ 6503' again still would not come free. Pulled 85 pts into tbg & left ON. DC: \$9,500 CC: \$221,930
- 01-21 SITP vac. Tbg still had 80 pts tension. PU 1-3/8" split shot & TIH on WL tag up @ 4525' would not go thru. POOH. PU 1-1/2" spud bar & TIH on WL worked dwn to 6465' solid spot again. POOH. PU 1-3/8" split shot & TIH on WL shoot collar @ 6441' w/split shot POOH. Did not come free. TIH w/free point tool to 6410' could not get thru collar @ 6441' try & free point tool not working properly scale getting inside slots. POOH w/free point tool. TIH w/spud bar worked dwn to 6454' got below collar @ 6441' & shoot, came free came free. RD WL, POOH & stand back 2-7/8" tbg LD jars & bumper sub & 97 jts 3-1/2" tbg still had some scale on outside & very few holes. Btm jt had split pin. Had to hammer on every collar to get loose completed @ 7:00 PM Saturday night. SI till Monday AM. DC: \$12,850 CC: \$234,780
- 01-23 SITP vac. PU 6-1/8" bit & TIH on 2-7/8" tbg tag up @ 3500'. RU swivel, wait on reverse unit pump delivery. Clean out dwn to 3620' returns show scale & iron. SDON (will clean out to top of fish @ 6441' & POOH, LD tbg Tuesday AM)
 DC: \$4,100 CC: \$238,880
- 01-24 SITP vac. Continue PU tbg & TIH w/6-1/8" bit, cleaned out to 5730' still getting returns of scale & iron. Circulate clean & SDON. (will clean out to top of fish @ 6441' & POOH, LD tbg this morning) DC: \$1,700 CC: \$240,580
- 01-25Continue PU tbg off ground & clean out scale & iron w/6-1/8" bit. Clean out to top of fish @
6435'. RD swivel & reverse unit. POOH, LD tbg. Remove BOP & flange up. Clean up location &
release all equipment. SDON.
DC: \$7,650 CC: \$248,230
- 01-26 RD PU & move to yard DC: \$345 CC: \$248,575 #128,173 Corrected total than 3/31/2001 JIB

6