

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. V-983

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry	7. Unit Agreement Name
2. Name of Operator Petrus Operating Company, Inc.	8. Farm or Lease Name State "A"
3. Address of Operator 12201 Merit Drive, Suite 900 Dallas, Texas 75251-2293	9. Well No. 1
4. Location of Well UNIT LETTER K 1874 FEET FROM THE South LINE AND 1874 FEET FROM THE West LINE, SECTION 34 TOWNSHIP 11S RANGE 33E NMPM.	10. Field and Pool, or Wildcat Bagley (Penn) <i>Atoka</i>
15. Elevation (Show whether DF, RT, GR, etc.) 4256' GL	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Move in and prepare to P&A 05-29-86.  
Mix and pump 300 sx cement in hole. Well on vacuum. Mix and pump 300 sx cement in hole on vacuum. Tubing stuck at 3800'. Cut off tubing at 3000'. Ran casing shot to 2502'. Pull & LD 5-1/2" casing. TIH to casing stub and spot 25 sx plug at 2502'. Mix and spot 35 sx plug 1700-1600'. Cut off 13-3/8" casing. Pump 10 sx surface plug. Weld on plate and dry hole marker. Well P&A'd 06-03-86.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Suzann Jourdan Suzann Jourdan

TITLE Regulatory Coordinator

DATE 07-15-86

APPROVED BY Jack Gillingham  
CONDITIONS OF APPROVAL, IF ANY:

TITLE OIL & GAS INSPECTOR

DATE APR 9 1987