

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 02915

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

--

7. UNIT AGREEMENT NAME

--

8. FARM OR LEASE NAME

Federal F

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Prairie, SA, South

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 21, T-8-S, R-36-E

12. COUNTY OR PARISH

Roosevelt

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

AMERICAN PETROFINA CO. OF TEXAS

3. ADDRESS OF OPERATOR

Box 1311, Big Spring, TX 79720

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

(Unit D) - 660' FNL and 660' FWL of section

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

+ 4,142 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

3-1-76 - Rigged up csg puller.

Set metal bridge plug at 4790'.

Cut 4-1/2" csg at 4449' and pulled.

Ran tbg to 4466', circulate hole, load with mud.

Mix and spot 35 sx cement at 4475'.

Mix and spot 40 sx cement at 4250'.

Mix and spot 35 sx cement at 2000'.

Cut 8-5/8" csg at 509' and pulled.

Ran tbg to 550' - Mix and spot 125 sx cement.

Set 15' cement plug at surface.

Place surface marker.

Clean location and ripped caliche on surface.

**Area to be sown with approved grass seed at proper season (see letter to
Dept. of Game & Fish, State of NM with form 9-331, 12-18-75).**

WJP/jc

18. I hereby certify that the foregoing is true and correct

SIGNED

J.C. Chapman

TITLE **Asst. Dist. Mgr. of Prod.**

DATE **May 3, 1976**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.