

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

PERMIT TO DRILL
(Other instructions on
reverse side)

Not approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-033910

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

McGrail Fed

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Allison-Pennsylvania

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

20-T8S-37E

12. COUNTY OR PARISH 13. STATE

Roosevelt

NM

1.

OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Tom L. Ingram

3. ADDRESS OF OPERATOR

POB 1757, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980 FWL & 660 FSL of Sec. 20

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)

4051 DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

March 25 thru 28, 1975:

Set CIBP @ 9100. Put 35' of cement on top. Cut 5½" csg. @ 4008 and pulled.
Put 100' plug in and out of 5½" csg and 9-5/8" csg. @ 4100.
Put 100' plug @ 2200. Put 10 sack plug @ surface with marker. Mud laden brine
used between all plugs.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Operator

DATE 6/4/76

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

JUN 7 1976

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLI
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42 R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-033910

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

McGrail Fed

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Allison-Pennsylvania

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

20-T8S-37E

12. COUNTY OR PARISH

Roosevelt

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
Tom L. Ingram

3. ADDRESS OF OPERATOR
POB 1757, Roswell, New Mexico 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980 FWL & 660 FSL of SEc. 20

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4051 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other) X Test San Andres

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Set CIBP @ 9100. Put 35' of cement on top. Cut casing @ 6000 and pull. Put 100' plug in and out of stub of 5 1/2" casing. Put 100' plug in and out of base of 9-5/8" csg. Put 100' plug @ top of salt @ 2200. Put 10 sack plug @ surface with marker. Mud laden fluid to be used between all plugs.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Operator

DATE

2/20/75

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side