

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-058677

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR Petroleum Corporation of Texas		8. FARM OR LEASE NAME Bate-Federal	
3. ADDRESS OF OPERATOR Box 911, Breckenridge, Texas 76024		9. WELL NO. 2	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL 1980' FWL Sec. 22, T8S, R36E		10. FIELD AND POOL, OR WILDCAT Prairie Cisco, South	
		11. SEC., T., R., E., OR BLK. AND SURVEY OR AREA Sec. 22, T8S, R36E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, CR, etc.) 4090' GL	12. COUNTY OR PARISH Roosevelt	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANS

(Other)

(Other) Recomplete in San Andres

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting, any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set CIBP @ ~~4885~~⁹⁰⁰⁰' w/35 sx. cement on top of plug.
2. Propose to set CIBP in 4½" csg. @ 5000'. Perforate 4½" csg. @ 4990' w/2 shots and cement w/150 sx. cement. If required, block squeeze @ 4700'.
3. Perforate San Andres zone @ 4810-4824' w/2 shots/ft.
4. Acidize interval 4810-24' w/2500 gallons MCA acid and ball sealers. Swab back and test.
5. Put well on beam pump.

18. I hereby certify that the foregoing is true and correct

SIGNED

Mary D. Taylor

TITLE

Production Clerk

DATE

12/16/74

(This space for Federal or State use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
AS AMENDED
DEC 23 1974ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side