

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

SEP 15 11 35 AM '65

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry Hole</b>		7. Unit Agreement Name
2. Name of Operator <b>Tom L. Ingram</b>		8. Farm or Lease Name <b>Wilson</b>
3. Address of Operator <b>P. O. Box 1757 - Roswell, New Mexico</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>M</b> , <b>554</b> FEET FROM THE <b>South</b> LINE AND <b>766</b> FEET FROM THE <b>West</b> LINE, SECTION <b>29</b> TOWNSHIP <b>8-S</b> RANGE <b>38-E</b> NMPM.		10. Field and Pool, or Wildcat <b>North Sawyer Devonian</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3966.6 GR</b>		12. County <b>Roosevelt</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

From 9-9-65 to 9-12-65 performed the following work:

Shot 8-5/8" at 2900, 2000, 1500, 1300 and 1205. Pulled 8-5/8" from surface to 1205. Set 100' plug in and out of the stub of the 8-5/8" at 1205, set 50' plug in and out of the surface at 400', 10-sack plug at surface and set marker.

Pits and location have been levelled. As soon as cellar is filled, will notify for final inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Tom L. Ingram TITLE Owner DATE 9-14-65

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: