

NO. OF COPIES RECEIVED		
DISTRIBUTION		
DATE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator <b>SUN OIL COMPANY</b>		8. Farm or Lease Name <b>James McFarland</b>	
3. Address of Operator <b>P. O. Box 1261, Midland, Texas 79701</b>		9. Well No. <b>1</b>	
4. Location of Well UNIT LETTER <b>N</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>1930</b> FEET FROM <b>West</b> <b>20</b> TOWNSHIP <b>73</b> RANGE <b>33E</b> NMPM.		10. Field and Pool, or Wildcat <b>Chaveroo San Andres</b>	
15. Elevation (Show whether DF, RT, GR, etc.) <b>GR. 4427</b>		12. County <b>Roosevelt</b>	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU.
2. Pull rods pump and tbq.
3. Run tbq. OE and spot 40 sx cmt plug 4300-4085 across perfs.
4. Pull up, wait 4 hrs, and tag plug. Circulate hole w/9.5# mud laden fluid. POH.
5. Locate free point shoot and pull 4 1/2" csg. Anticipate 3000' recovery.
6. Run tbq spot 30 sx cmt plug 50' in and out of 4 1/2" csg stub.
7. Spot 50 sx cmt plug 2400-2300 at base of salt.
8. Spot 50 sx cmt plug 2000-1900 at top of salt.
9. Spot 50 sx cmt plug 440-330 across 8-5/8" casing seat.
10. Spot 10 sx cmt plug at surface, weld in cap and install permanent marker.

Use Class "H" cmt., mud laden fluid between all plugs.

THE COMMISSION MUST BE NOTIFIED 24  
HOURS PRIOR TO THE BEGINNING OF  
PLUGGING OPERATIONS FOR THE C-103  
TO BE APPROVED.

*Expires 4/1/77*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles Gray TITLE Proration Analyst DATE 9/27/76

APPROVED BY [Signature] TITLE [Signature] DATE 9/27/76

CONDITIONS OF APPROVAL, IF ANY:

ATTACHED

SEP 11 1976

OR CONSERVATION COMM.  
LUDDS, R. M.