

COPIES RECEIVED	
DISTRIBUTION	
FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-1276	
7. Unit Agreement Name	
8. Farm or Lease Name	
State DB	
9. Well No.	
6	
10. Field and Pool, or Wildcat	
Chaveroo	
12. County	
Roosevelt	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Braden-Deem, Inc.		State DB
3. Address of Operator		9. Well No.
Suite 1250, 125 N. Market, Wichita, Ks 67202		6
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER M 660 FEET FROM THE South LINE AND 660 FEET FROM		Chaveroo
THE West LINE, SECTION 25 TOWNSHIP 7S RANGE 33E NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4335 RDB		Roosevelt

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

### NOTICE OF INTENTION TO:

### SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER Convert to water injection well <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Perforated San Andres; 4189-91, 4202-04, 4227-30, 4236-38, 4254-58, 4271-75, 4278-81, 4285-94, 4302-04, 4311-13, 4352-68 & 4372-82.
2. Acidize w/4000 gals acid using ball sealers.
3. Set Baker AD packer @ 4150 on 2" Duo-lined tubing. Circulate treated water behind packer.
4. Pressure test tubing - casing annulus on top of packer to 500 psi. Tested OK. State man on location to witness test.
5. Started injecting water on 3/30/85. Taking water on vacuum.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Day C. Deem

SIGNED \_\_\_\_\_ TITLE President DATE 4/11/85

DISTRICT 1 SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE APR 29 1985

CONDITIONS OF APPROVAL, IF ANY: