

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR GEROR, INC.		8. FARM OR LEASE NAME FEDERAL 19	
3. ADDRESS OF OPERATOR 1846 East Broadway, Tucson, Arizona 85719		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660/S 1980/E		10. FIELD AND POOL, OR WILDCAT Chaveroo San Andres	
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 19 - T7S - R33E	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) Gr 4336 KB 4348		12. COUNTY OR PARISH Reasuvault	
		13. STATE N Mex	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

9-18-68 - Ran 365' - 8 5/8" - 20# new casing @ 375' depth - cemented with 275 sacks cement with 2% CaCl₂ - Halliburton - circulate out 15 sacks
9-19 Test casing with 600# for 30 minutes - okay
9-28 Ran 138 jts - 4348' - 5 1/2" - 14# - new casing @ 4358' depth - cemented with 350 sacks Incoor poemix + 100 sacks Gilsontite - 400 sacks mixed.
9-30 Ran cement bond log - Schlumberger - top cement 3160'. No cement 4260-4360'. Perforate 2/F 4264 & 4352 for squeeze.
10-1 Squeeze perfs with 100 sacks neat cement @ 2000# pressure.
10-2 Drillout to 4348' - run bond log - still short of cement at bottom. Perforate 4/F @ 4300' for squeeze.
10-3 Squeeze perfs with 200 sacks neat cement @ 2000# pressure.
10-4 Drill out to 4348' - ran bond log - okay
Perforate casing for completion - 14 - 3/8" holes @ 4177, 4209, 15, 19, 32, 35, 43, 47, 52, 59, 66, 72, 77, 83.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

11/19/68

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

NOV 21 1968

*See Instructions on Reverse Side

J. L. GORDON
ACTING DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.